




Digital clamp meter

AX-3550



Instruction Manual





1. Safety Information





To avoid possible electric shock or personal injury, and to avoid possible damage to the Meter or to the equipment under test, adhere to the following rules:

1. Before using the Meter inspect the case. Do not use the Meter if it is damaged or the case (or part of the case) is removed. Look for cracks or missing plastic. Pay attention to the insulation around the connectors.
2. Inspect the test leads for damaged insulation or exposed metal. Replace damaged test leads with identical model number or electrical specifications before using the Meter.
3. Do not apply more than the rated voltage, as marked on the Meter.
4. When measurement has been completed, disconnect the connection between the test leads and the circuit under test, remove the test leads away from the input terminals of the Meter and turn the Meter power off.
5. Do not carry out the measurement when the Meter's back case and / or battery door is opened to avoid electric shock.
6. When the Meter working at an effective voltage over 30V in AC, special care should be taken.
7. Use the proper terminals and function you're your measurements.
8. Do not use or store the Meter in an environment of high temperature, humidity, explosive, inflammable and strong magnetic field. The performance of the Meter may deteriorate after dampened.
9. Do not use the Meter if the surface of it is wet or the user's hands are wet.
10. When using the test leads, keep your fingers behind the finger guards





2. Function


Button	Operation Performed
HOLD	<p>Press HOLD to enter the Hold mode any mode,  appears and the Meter beeps.</p> <p>Press HOLD again to exit the Hold mode to return to measurement mode, the Meter beeps and,  disappears.</p>
	<p>Press the backlight button when needed. Auto shut-down backlight after lighting 20secs. Press the button again, turn the backlight off manually</p>
Σ	<p>At Active power (main display) + Phase angle (secondary display) mode, press Σ once button to sum up the current phase of 3 phase measurement result. Then carry out second phase power measurement.</p> <p>Press Σ and hold for over 1 second to sum up the phase power measurement result which had been selected.</p> <p>if you didn `t select any phase of 3 phase, Σ is invalid.</p>
SAVE	<p>Press once to store single reading, and the Meter beeps. The index number shown on the left secondary display keep on increasing. The maximum number of data store is 99, when it achieves 99, the Meter shows .</p>
SEL	<p>Press SEL button to step through first phase, second phase, third phase and sum of watts.</p> <p>Press SEL and hold for over 2 second to enter 3P3W mode.</p>
MAXMIN	<p>Press to start recording of maximum it valid at voltage, current, active power and apparent power ranges only.</p>
CLEAR	<p>At active energy range, press CLEAR and hold for over 1 second to reset time the zero, then restart the timing.</p> <p>At all other ranges, press CLEAR and hold for over 1 second to clear stored</p>



AXIOMET

	readings.
MR	Press once to enter Memory Record mode, MIR appears and the Meter beeps.
□/□	If the Meter steps through sum of power press □/□ button to switch display of active power (main display) , sum of reactive power (secondary display) , sum of power factor (main display) and sum of apparent power. In the MR mode, press □/□ to select recoded data.
USB	Measurement data will be sent to the PC

2.1. Additional information

1. Turn the rotary switch deasil to make the position away from the OFF position. Hearing a beep sound indicates the meter is turned on. The LCD displays all symbols firstly and then return to the normal mode. If the symbol  is displayed, please changed the battery.
2. After auto-shut-off, there are some parts of the circuit of the meter which is still work. If no measurement needed in a longer time, you'd better turn the rotary switch back to the OFF position.
3. Press the backlight button when needed. Auto shut-down backlight after lighting 18secs. Press the button again, turn the backlight off manually

3. Display symbols











Figure 1



AXIO

IIIIIIII MET

USB	Data Output is in progress
	First phase symbol
	Second phase symbol
	Third phase symbol
h	Unit for hour
mm	Unit for minute
HZ	Hz: Hertz. The unit of frequency.
PG	PG: The unit of phase angle
KVAr	KVAr. The unit of reactive power
ΣW	Watt: Sum of Watt
	<p>The battery is low.</p> <p>⚠ Warning: To avoid false readings, which could lead to possible electric shock or personal injury, replace the battery as soon as the battery indicator appears.</p>
S	Unit for second
MAX/MIN	Maximum and Minimum reading
	Analogue Bar Graph
	Overloading
	Ruler
CLEAR	Indicator for clear the stored reading





	Negative symbol
	High voltage symbol
AC	Indicator for AC voltage or current
MR	Indicator for recall the stored reading
Hz	Frequency symbol
MEM	Indicator for data store
FUL	Indicator for data stored is full
	Data hold is active

4. Specifications

AC Voltage (True RMS)

Range	Resolution	Accuracy	Allowable Maximum overload protection voltage	Input Impedance	Frequency Range
100V	0.1V	$\pm(1.2\%+5)$	750 RMS	10M	50Hz-200Hz
400V					
750V					

Frequency

Range	Resolution	Accuracy





50Hz-200Hz	1Hz	±(0.5%+5)
------------	-----	-----------

AC Current (True RMS)

Range	Resolution	Accuracy	Allowable Maximum overload protection current	Frequency Range
40A	0.1A	±(2%+5)	1000A RMS	50Hz-60Hz
100A				
400A				
1000A	1A			

Active Power ($W=V \times A \times \cos\theta$)

Current / Voltage		Voltage Range		
		100V	400V	750V
Current Range	40A	4.00KW	16.00KW	30.00KW
	100A	10.00KW	40.00KW	75.00KW





	400A	40.00KW	160.0KW	300.0KW
	1000A	100.0KW	400.0KW	750.0KW
Accuracy	±(3%+5)			
Resolution	<1000KW: 0.01KW 100kW: 0.1KW			

Apparent Power (VA = V x A)

Current / Voltage		Voltages Range		
		100V	400V	750V
Current Range	40A	4.00KVA	16.00KVA	30.00KVA
	100A	10.00KVA	40.00KVA	75.00KVA
	400A	40.00KVA	160.0KVA	300.0KVA
	1000A	100.0KVA	400.0KVA	750.0KVA
Accuracy		±(3%+5)		
Resolution		<1000KVA: 0.01KVA 100kW: 0.1KVA		

Reactive Power (Var = V x A x SINθ)

Current / Voltage	Voltages Range
-------------------	----------------





		100V	400V	750V
Current Range	40A	4.00KVA _r	16.00KVA _r	30.00KVA _r
	100A	10.00KVA _r	40.00KVA	75.00KVA _r
	400A	40.00KVA _r	160.0KVA _r	300.0KVA _r
	1000A	100.0KVA _r	400.0KVA _r	750.0KVA _r
Accuracy		±(3%+5)		
Resolution		<1000KVA _r : 0.01KVA _r 100kW: 0.1KVA _r		

Power Factor (PF = W / VA)

Range	Accuracy	Resolution	Measuring Condition
0.3-1 (capacitive or inductive)	±0.022	0.001	The minimum measuring current 10A The minimum measuring voltage 45V
0.3-1 (capacitive or inductive)	For reference only		Measuring current less than 10A OR Measuring voltage less than 45V

Active Energy (kWh)

Range	Accuracy	Resolution
1-9999kWh	±(3%+2)	0.001kWh





Phase Angle (PG=acos (PF))

Range	Accuracy	Resolution	Measuring Condition
0° -90° (capacitive or inductive)	±2°	1°	The minimum measuring current 10A The minimum measuring voltage 45V
0° -90° (capacitive or inductive)	For reference only		Measuring current less than 10A OR Measuring voltage less than 45V

Remarks:

- ⚡ Allowable maximum overload protection voltage: 750V RMS
- ⚡ Allowable maximum overload protection current: 1000A RMS

Basic Functions	Range	Best Accuracy
AC Voltage	100V/400V/750V	±(1.2%+5digits)
AC Current	40A/100A/400A/1000A	±(2%+5 digits)
Active Power	0.01kW-750kW	±(3%+5 digits)
Apparent Power	0.01kVA-750kVA	±(3%+5 digits)
Reactive Power	0.01kVAr-750kVAr	±(4%+5 digits)






Power Factor	0.3-1(Capacitive or Inductive)	±(0.02+2 digits)
Phase Angle	0° -90°	±2°
Frequency	50Hz-200Hz	✓
Active Energy	0.001-9999 kWh	±(3%+2 digits)
Temperature	-50°C-1300°C -58°F-2372°F	
Special Functions		
Auto Ranging		✓
Single-phase 2-wire		✓
Balance 3-phase 3-wire		✓
3-phase 4-wire		✓
True RMS	AC Voltage or Curren	✓
Data Logging	99	✓
Data Recall		✓
Max/Min Mode		✓
Data Hold		✓
USB		✓
Display Backlight		✓
Full Icon Display		✓





Sleep Mode		<i>f</i>
Low Battery Display		<i>f</i>
Input Impedance for AC Voltage Measurement	Around 10MW	<i>f</i>
Max. Display	9999	<i>f</i>
Analogue Bar Graph		<i>f</i>

5. Battery replacement

1. Replace the battery as soon as the battery indicator  appears. With a low battery, the Meter might produce false readings that can lead to electric shock and personal injury.
2. When opening the battery door, must make sure the Meter is power off.
3. When servicing the Meter, use only the same model number or identical electrical specifications replacement parts.
4. Battery type: 9V battery.

