

Agilent U1251B and U1252B Handheld Digital Multimeter

User's and Service Guide



Agilent Technologies

Notices

© Agilent Technologies, Inc. 2009–2013

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Agilent Technologies, Inc. as governed by United States and international copyright laws.

Manual Part Number

U1251-90036

Edition

Tenth Edition, August 12, 2013

Printed in Malaysia

Agilent Technologies, Inc.
5301 Stevens Creek Blvd.
Santa Clara, CA 95051 USA

Technology Licenses

The hardware and/or software described in this document are furnished under a license and may be used or copied only in accordance with the terms of such license.

Restricted Rights Legend

U.S. Government Restricted Rights. Software and technical data rights granted to the federal government include only those rights customarily provided to end user customers. Agilent provides this customary commercial license in Software and technical data pursuant to FAR 12.211 (Technical Data) and 12.212 (Computer Software) and, for the Department of Defense, DFARS 252.227-7015 (Technical Data - Commercial Items) and DFARS 227.7202-3 (Rights in Commercial Computer Software or Computer Software Documentation).

Warranty

The material contained in this document is provided “as is,” and is subject to being changed, without notice, in future editions. Further, to the maximum extent permitted by applicable law, Agilent disclaims all warranties, either express or implied, with regard to this manual and any information contained herein, including but not limited to the implied warranties of merchantability and fitness for a particular purpose. Agilent shall not be liable for errors or for incidental or consequential damages in connection with the furnishing, use, or performance of this document or of any information contained herein. Should Agilent and the user have a separate written agreement with warranty terms covering the material in this document that conflict with these terms, the warranty terms in the separate agreement shall control.

Accessories Warranty

Agilent offers warranty for product’s accessories for up to 3 months from the end-user acceptance date.

Standard Calibration Service (optional)

Agilent offers an optional calibration service contract for a period of 3 years from end-user acceptance date.

Safety Notices

CAUTION

















A **CAUTION** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a **CAUTION** notice until the indicated conditions are fully understood and met.

WARNING

A **WARNING** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in personal injury or death. Do not proceed beyond a **WARNING** notice until the indicated conditions are fully understood and met.

Safety Symbols

The following symbols on the instrument and in the documentation indicate precautions which must be taken to maintain safe operation of the instrument.

| | | | |
|---|--|---|--|
|  | Direct current (DC) |  | Off (supply) |
|  | Alternating current (AC) |  | On (supply) |
|  | Both direct and alternating current |  | Caution, risk of electric shock |
|  | Three-phase alternating current |  | Caution, risk of danger (refer to this manual for specific Warning or Caution information) |
|  | Earth (ground) terminal |  | Caution, hot surface |
|  | Protective conductor terminal |  | Out position of a bi-stable push control |
|  | Frame or chassis terminal |  | In position of a bi-stable push control |
|  | Equipotentiality | CAT III 1000 V | Category III 1000 V overvoltage protection |
|  | Equipment protected throughout by double insulation or reinforced insulation | CAT IV 600 V | Category IV 600 V overvoltage protection |

Safety Information

This meter is safety-certified in compliance with EN/IEC 61010-1:2001, UL 61010-1 Second Edition and CAN/CSA 22.2 61010-1 Second Edition, CAT III 1000 V/ CAT IV 600 V Overvoltage Protection, Pollution Degree II. Use with standard or compatible test probes.

General Safety Information


The following general safety precautions must be observed during all phases of operation, service, and repair of this instrument. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended use of the instrument. Agilent Technologies assumes no liability for the customer's failure to comply with these requirements.

CAUTION







- Turn off the circuit power and discharge all high-voltage capacitors in the circuit before you perform resistance, continuity, diodes, or capacitance tests.
 - Use the correct terminals, function, and range for your measurements.
 - Never measure voltage when current measurement is selected.
 - Use only recommended rechargeable battery. Ensure proper insertion of battery in the meter, and follow the correct polarity.
 - Disconnect test leads from all the terminals during battery charging.
-

WARNING

- When working above 70 VDC, 33 VAC RMS or 46.7 V peak, exercise caution – such range pose a shock hazard.
- Do not measure more than the rated voltage (as marked on the meter) between terminals, or between terminal and earth ground.
- Double-check the meter's operation by measuring a known voltage.
- For current measurement, turn off circuit power before connecting the meter to the circuit. Always place the meter in series with the circuit.
- When connecting probes, always connect the common test probe first. When disconnecting probes, always disconnect the live test probe first.
- Detach test probes from the meter before you open the battery cover.
- Do not use the meter with the battery cover or part of the cover removed or loose.

- Replace the battery as soon as the low battery indicator  flashes on screen. This is to avoid false readings, which may lead to possible electric shock or personal injury.
- Do not operate the product in an explosive atmosphere or in the presence of flammable gases or fumes.
- Inspect the case for cracks or missing plastic. Pay extra attention to the insulation surrounding the connectors. Do not use the meter if it is damaged.
- Inspect the test probes for damaged insulation or exposed metal, and check for continuity. Do not use the test probe if it is damaged.
- Do not use any other AC charger adaptor apart from the one certified by Agilent with this product.
- Do not use repaired fuses or short-circuited fuse-holders. For continued protection against fire, replace the line fuses only with fuses of the same voltage and current rating and recommended type.
- Do not service or perform adjustments alone. Under certain condition, hazardous voltages may exist, even with the equipment switched off. To avoid dangerous electric shock, service personnel must not attempt internal service or adjustment unless another person, capable of rendering resuscitation or first aid, is present.
- Do not substitute parts or modify equipment to avoid the danger of introducing additional hazards. Return the product to Agilent Technologies Sales and Service Office for service and repair to ensure the safety features are maintained.
- Do not operate damaged equipment as the safety protection features built into this product may have been impaired, either through physical damage, excessive moisture, or any other reason. Remove power and do not use the product until safe operation can be verified by service-trained personnel. If necessary, return the product to Agilent Technologies Sales and Service Office for service and repair to ensure the safety features are maintained.

Regulatory Markings

| | | | |
|---|---|---|---|
|  | <p>The CE mark is a registered trademark of the European Community. This CE mark shows that the product complies with all the relevant European Legal Directives.</p> |  | <p>The C-tick mark is a registered trademark of the Spectrum Management Agency of Australia. This signifies compliance with the Australia EMC Framework regulations under the terms of the Radio Communication Act of 1992.</p> |
| <p>ICES/NMB-001</p> | <p>ICES/NMB-001 indicates that this ISM device complies with the Canadian ICES-001. Cet appareil ISM est conforme a la norme NMB-001 du Canada.</p> |  | <p>This instrument complies with the WEEE Directive (2002/96/EC) marking requirement. This affixed product label indicates that you must not discard this electrical/electronic product in domestic household waste.</p> |
|  | <p>The CSA mark is a registered trademark of the Canadian Standards Association.</p> |  |  |

Waste Electrical and Electronic Equipment (WEEE) Directive 2002/96/EC

This instrument complies with the WEEE Directive (2002/96/EC) marking requirement. This affixed product label indicates that you must not discard this electrical/electronic product in domestic household waste.

Product Category:

With reference to the equipment types in the WEEE directive Annex 1, this instrument is classified as a "Monitoring and Control Instrument" product.

The affixed product label is as shown below.



Do not dispose in domestic household waste

To return this unwanted instrument, contact your nearest Agilent Technologies, or visit: www.agilent.com/environment/product for more information.

Agilent Technologies, through Rechargeable Battery Recycling Corporation (RBRC), offers free and convenient battery recycling options in the U.S. and Canada. Contact RBRC at 877-2-RECYCLE (877.273.2925) or online at: <http://www.call2recycle.org/> for the nearest recycling location.

In This Guide...

1 Getting Started

This chapter contains information on the Agilent U1251B and U1252B handheld multimeter front panel, rotary switch, keypad, display, terminals and rear panel.

2 Making Measurements

This chapter contains information on how to make measurements using the U1251B and U1252B handheld digital multimeter.

3 Functions and Features

This chapter contains information on the functions and features that are available for the U1251B and U1252B digital multimeter.

4 Changing The Default Setting

This chapter shows you how to change the default factory settings of the U1251B and U1252B and other available setting options.

5 Maintenance

This chapter will go through how to troubleshoot the handheld digital multimeter if any problems arise.

6 Performance Tests and Calibration

This chapter contains the performance test procedures and the adjustment procedure.

7 Specifications

This chapter lists the product characteristics, specification assumptions and the specifications of the U1251B and U1252B digital multimeters.

Declaration of Conformity (DoC)

The Declaration of Conformity (DoC) for this instrument is available on the Web site. You can search the DoC by its product model or description.

<http://regulations.corporate.agilent.com/DoC/search.htm>

NOTE

If you are unable to search for the respective DoC, please contact your local Agilent representative.

Contents

1 Getting Started

| | |
|---|----|
| Introducing the U1251B/U1252B Handheld Digital Multimeter | 2 |
| Check the shipment | 3 |
| Adjusting the tilt-stand | 4 |
| The front panel at a glance | 6 |
| The rear panel at a glance | 7 |
| The rotary switch at a glance | 8 |
| The keypad at a glance | 9 |
| The display at a glance | 11 |
| Selecting display with the Hz button | 15 |
| Selecting display with the Dual button | 17 |
| Selecting display with the Shift button | 20 |
| The terminals at a glance | 22 |

2 Making Measurements

| | |
|--|----|
| Understanding The Measurement Instructions | 24 |
| Measuring Voltage | 24 |
| Measuring AC voltage | 25 |
| Measuring DC voltage | 26 |
| Measuring AC and DC Signals (U1252B only) | 27 |
| Measuring Current | 28 |
| μ A & mA measurement | 28 |
| Percentage scale of 4 mA to 20 mA | 30 |
| A (ampere) measurement | 32 |
| Frequency Counter | 33 |
| Measuring Resistance, Conductance and Testing Continuity | 35 |
| Testing Diodes | 40 |

| | |
|---------------------------------------|----|
| Measuring Capacitance | 43 |
| Measuring Temperature | 45 |
| Alerts and Warning During Measurement | 49 |
| Overload alert | 49 |
| Input warning | 49 |
| Charge terminal alert | 50 |

3 Functions and Features

| | |
|---------------------------------|----|
| Dynamic Recording | 52 |
| Data Hold (Trigger Hold) | 54 |
| Refresh Hold | 55 |
| Null (Relative) | 57 |
| Decibel Display | 59 |
| 1 ms Peak Hold | 61 |
| Data Logging | 63 |
| Manual logging | 63 |
| Interval logging | 65 |
| Reviewing logged data | 67 |
| Square Wave Output (for U1252B) | 69 |
| Remote Communication | 73 |

4 Changing The Default Setting

| | |
|---|----|
| Selecting Setup Mode | 76 |
| Setting Data Hold/Refresh Hold Mode | 80 |
| Setting Data Logging Mode | 81 |
| Setting Thermocouple Types (U1252B only) | 82 |
| Setting Reference Impedance for dBm Measurement | 83 |

| | |
|---------------------------------------|----|
| Setting Minimum Frequency Measurement | 84 |
| Setting Temperature Unit | 85 |
| Setting Auto Power Saving Mode | 87 |
| Setting Percentage (%) Scale Readout | 89 |
| Setting Beep Frequency | 90 |
| Setting Backlight Timer | 91 |
| Setting Baud Rate | 92 |
| Setting Parity Check | 93 |
| Setting Data Bit | 94 |
| Setting Echo Mode | 95 |
| Setting Print Mode | 96 |
| Returning to Default Factory Settings | 97 |
| Setting the Battery Voltage | 98 |
| Setting the Filter | 99 |

5 Maintenance

| | |
|----------------------------|-----|
| Introduction | 102 |
| General maintenance | 102 |
| Battery replacement | 102 |
| Storage considerations | 104 |
| Charging the battery | 105 |
| Fuse checking procedure | 112 |
| Replacing the fuse | 114 |
| Troubleshooting | 116 |
| Replaceable Parts | 118 |
| To order replaceable parts | 118 |

6 Performance Tests and Calibration

| | |
|---|-----|
| Calibration Overview | 120 |
| Closed-case electronic calibration | 120 |
| Agilent Technologies calibration services | 120 |
| Calibration interval | 121 |
| Adjustment is recommended | 121 |
| Recommended Test Equipment | 122 |
| Basic Operating Test | 123 |
| Backlit test | 123 |
| Testing the display | 123 |
| Current terminal test | 124 |
| Charge terminal alert test | 125 |
| Test Considerations | 126 |
| Calibration Security | 127 |
| Performance Verification Tests | 128 |
| Unsecuring the instrument for calibration | 136 |
| Calibration Process | 139 |
| Using the front panel for adjustments | 140 |
| Adjustments Consideration | 141 |
| Valid adjustment input values | 142 |
| Adjustment Procedure | 143 |
| Finishing the Adjustment | 150 |
| To Read the Calibration Count | 150 |
| Calibration Errors | 151 |

7 Specifications

| | |
|---------------------------------|-----|
| Product Characteristics | 154 |
| Measurement Category | 157 |
| Measurement category definition | 157 |

| | |
|---|-----|
| Specification Assumptions | 158 |
| Electrical Specifications | 158 |
| DC Specifications | 158 |
| AC Specifications | 161 |
| AC+DC Specifications for U1252B | 163 |
| Capacitance Specifications | 164 |
| Temperature Specifications | 164 |
| Frequency Specifications | 165 |
| Duty Cycle and Pulse Width Specifications | 165 |
| Frequency Sensitivity Specifications | 166 |
| Peak Hold Specifications | 168 |
| Frequency Counter Specifications for U1252B | 168 |
| Square Wave Output for U1252B | 169 |
| Operating Specifications | 171 |
| Display update rate (approximate) | 171 |
| Input impedance | 172 |

List of Figures

| | | |
|-------------|---|----|
| Figure 1-1 | Tilt-stand at 60° | 4 |
| Figure 1-2 | Tilt-stand at 30° | 4 |
| Figure 1-3 | Tilt-stand at hanging position | 5 |
| Figure 1-4 | U1252B front panel | 6 |
| Figure 1-5 | Rear panel | 7 |
| Figure 1-6 | Rotary switch | 8 |
| Figure 1-7 | U1252B keypad | 9 |
| Figure 1-8 | Display symbols | 11 |
| Figure 1-9 | Connector terminals | 22 |
| Figure 2-1 | Measuring AC voltage | 25 |
| Figure 2-2 | Measuring DC voltage | 26 |
| Figure 2-3 | Measuring mA and mA current | 29 |
| Figure 2-4 | Measuring scale of 4-20 mA | 31 |
| Figure 2-5 | A (ampere) current measurement | 32 |
| Figure 2-6 | Measuring frequency | 34 |
| Figure 2-7 | Measuring resistance | 36 |
| Figure 2-8 | Audible continuity, conductance, and resistance test. | 37 |
| Figure 2-9 | Conductance measurement | 39 |
| Figure 2-10 | Measuring forward bias of diode | 41 |
| Figure 2-11 | Measuring reverse bias of diode | 42 |
| Figure 2-12 | Capacitance measurements | 44 |
| Figure 2-13 | Connecting the thermal probe into the non-compensation transfer adapter | 46 |
| Figure 2-14 | Connecting the probe with adapter into the multimeter | 46 |
| Figure 2-15 | Surface temperature measurement | 48 |
| Figure 2-16 | Input terminal warning | 49 |
| Figure 2-17 | Charge terminal alert | 50 |
| Figure 3-1 | Dynamic recording mode operation | 53 |
| Figure 3-2 | Data hold mode operation | 54 |
| Figure 3-3 | Refresh hold mode operation | 56 |
| Figure 3-4 | Null (relative) mode operation | 58 |
| Figure 3-5 | dBm/dBV display mode operation | 60 |
| Figure 3-6 | 1 ms peak hold mode operation | 62 |
| Figure 3-7 | Hand (Manual) logging mode operation | 64 |

| | | |
|-------------|---|-----|
| Figure 3-8 | Full Log | 64 |
| Figure 3-9 | Interval (Automatic) logging mode operation | 66 |
| Figure 3-10 | Log review mode operation | 68 |
| Figure 3-11 | Frequency adjustment for square wave output | 70 |
| Figure 3-12 | Duty cycle adjustment for square wave output | 71 |
| Figure 3-13 | Pulse width adjustment for square wave output | 72 |
| Figure 3-14 | Cable connection for remote communication | 73 |
| Figure 4-1 | Data hold/Refresh hold setup | 80 |
| Figure 4-2 | Data logging setup | 81 |
| Figure 4-3 | Thermocouple type setup | 82 |
| Figure 4-4 | Reference impedance for dBm measurement setup | 83 |
| Figure 4-5 | Minimum frequency setup | 84 |
| Figure 4-6 | Temperature unit setup | 86 |
| Figure 4-7 | Auto power saving setup | 88 |
| Figure 4-8 | % scale readout setup | 89 |
| Figure 4-9 | Beep frequency setup | 90 |
| Figure 4-10 | Backlit timer setup | 91 |
| Figure 4-11 | Baud rate setup remote control | 92 |
| Figure 4-12 | Parity check setup | 93 |
| Figure 4-13 | Data bit setup for remote control | 94 |
| Figure 4-14 | Echo mode setup for remote control | 95 |
| Figure 4-15 | Print mode setup for remote control | 96 |
| Figure 4-16 | Reset setup | 97 |
| Figure 4-17 | Battery voltage selection | 98 |
| Figure 4-18 | DC filter | 99 |
| Figure 5-1 | 9 V rectangular battery | 104 |
| Figure 5-2 | Battery capacity display as trickle | 107 |
| Figure 5-3 | Self-test | 108 |
| Figure 5-4 | Charging mode | 110 |
| Figure 5-5 | Charge end and trickle state | 110 |
| Figure 5-6 | Battery charging procedure | 111 |
| Figure 5-7 | Fuse checking procedures | 112 |
| Figure 5-8 | Fuse replacement | 115 |
| Figure 6-1 | LCD display | 123 |
| Figure 6-2 | Input warning | 124 |
| Figure 6-3 | Charge terminal alert | 125 |

List of Tables

| | | |
|------------|---|-----|
| Table 1-1 | Rotary switch description and functions | 8 |
| Table 1-2 | Keypad descriptions and functions | 9 |
| Table 1-3 | General display symbols | 12 |
| Table 1-4 | Primary display symbols | 13 |
| Table 1-5 | Secondary display symbols | 14 |
| Table 1-6 | Analog bar range and counts | 15 |
| Table 1-7 | Selecting display with the Hz button | 16 |
| Table 1-8 | Selecting display with the Dual button | 18 |
| Table 1-9 | Selecting display with the Shift button | 20 |
| Table 1-10 | Terminal connections for different measuring functions | 22 |
| Table 2-1 | Numerical steps descriptions | 24 |
| Table 2-2 | Percentage scale and measurement range | 30 |
| Table 2-3 | Audible continuity measurement range | 37 |
| Table 4-1 | Available setting options in Setup mode | 77 |
| Table 4-2 | Filter defaults | 100 |
| Table 5-1 | Battery voltage and corresponding percentage of charges in standby and charging modes | 106 |
| Table 5-2 | Error messages | 108 |
| Table 5-3 | Measurement readings for fuse checking | 113 |
| Table 5-4 | Fuse specifications | 115 |
| Table 5-5 | Basic troubleshooting procedures | 116 |
| Table 6-1 | Recommended Test Equipment | 122 |
| Table 6-2 | Verification Test | 129 |
| Table 6-3 | Valid adjustment input values | 142 |
| Table 6-4 | Adjustment table | 145 |
| Table 6-5 | Calibration error codes and their respective meanings | 151 |
| Table 7-1 | DC Accuracy \pm (% of reading + Number of Least Significant Digit) | 158 |
| Table 7-2 | U1251B accuracy specifications \pm (% of reading + number of LSD) for true RMS AC voltage | 161 |
| Table 7-3 | U1251B accuracy specifications \pm (% of reading + number of LSD) for true RMS AC current | 161 |
| Table 7-4 | U1252B accuracy specifications \pm (% of reading + number of LSD) for true RMS AC voltage | 162 |

| | | |
|------------|---|-----|
| Table 7-5 | U1252B accuracy specifications \pm (% of reading + number of LSD) for true RMS AC current | 162 |
| Table 7-6 | U1252B true RMS ac+dc voltage specifications | 163 |
| Table 7-7 | U1252B true RMS ac+dc current specifications | 163 |
| Table 7-8 | Capacitance specifications | 164 |
| Table 7-9 | Temperature specifications | 164 |
| Table 7-10 | Frequency specifications | 165 |
| Table 7-11 | Duty cycle and pulse width specifications | 165 |
| Table 7-12 | Frequency sensitivity and trigger level specifications for voltage measurements | 166 |
| Table 7-13 | Frequency sensitivity specifications for current measurements | 167 |
| Table 7-14 | Peak hold specifications for dc voltage and current measurements | 168 |
| Table 7-15 | Frequency counter (divide by 1) specifications | 168 |
| Table 7-16 | Frequency counter (divide by 100 ^[4]) specifications | 169 |
| Table 7-17 | Square wave output specifications | 169 |
| Table 7-18 | Display update rate (approximate) | 171 |
| Table 7-19 | Input Impedance | 172 |



1 Getting Started

Introducing the U1251B/U1252B Handheld Digital Multimeter 2

Check the shipment 3

Adjusting the tilt-stand 4

The front panel at a glance 6

The rear panel at a glance 7

The rotary switch at a glance 8

The keypad at a glance 9

The display at a glance 11

 Selecting display with the Hz button 15

 Selecting display with the Dual button 17

 Selecting display with the Shift button 20

The terminals at a glance 22

This chapter contains information on the Agilent U1251B and U1252B handheld multimeter front panel, rotary switch, keypad, display, terminals and rear panel.



Introducing the U1251B/U1252B Handheld Digital Multimeter

Key features of this digital multimeter:

- DC, AC and AC + DC (U1252B only) voltage and current measurements.
- True-RMS measurement for both AC voltage and current
- Rechargeable Ni-MH battery with built-in charging capability (U1252B only)
- Ambient temperature on second display
- Battery capacity indicator
- Bright orange LED backlight
- Resistance measurement of up to 50 M Ω (for U1251B) and 500 M Ω (for U1252B)
- Conductance measurement from 0.01 nS (100 G Ω) ~50 nS
- Capacitance measurement of up to 100 mF
- Frequency counter of up to 20 MHz (U1252B only)
- The % scale readout for 4–20 mA or 0–20 mA measurement
- dBm with selectable reference impedance
- 1 ms Peak Hold to catch inrush voltage and current easily
- Temperature test with selectable 0 °C compensation (without ambient temperature compensation).
- K-type (for U1251B) and J/K-types temperature measurement (U1252B only)
- Frequency, duty cycle, and pulse width measurements
- Dynamic Recording for min, max, and average readings
- Data Hold with manual or auto trigger and Null mode
- Diode and audible continuity tests
- Square wave generator with selectable frequency, pulse width and duty cycle (U1252B only)
- Agilent GUI Application Software (IR-USB cable sold separately)
- Closed case calibration

Check the shipment

Verify that you have received the following items with your multimeter:

- 9 V alkaline battery (U1251B only)
- 4 mm probes
- Test leads
- Alligator clips
- Rechargeable 8.4 V battery (U1252B only)
- Power cord & AC adapter (U1252B only)
- Quick Start Guide
- Certificate of Calibration

Contact your nearest Agilent Sales Office if any of the above are missing.

Inspect the shipping container for damage. Signs of damage may include a dented or torn shipping container or cushioning material that indicates signs of unusual stress or compacting. Save the packaging material in case the multimeter needs to be returned.

Please refer to the [Agilent Handheld Tools](#) brochure (5989-7340EN) for the full and latest list of handheld accessories available.

Adjusting the tilt-stand

To adjust the meter to a 60° standing position, pull the tilt-stand outwards to its maximum reach.




Figure 1-1 Tilt-stand at 60°

To adjust the meter to a 30° standing position, bend the tip of the stand so that it is parallel to the ground before pulling the stand outwards to its maximum reach.




Figure 1-2 Tilt-stand at 30°

To adjust the meter to a hanging position follow the steps shown in [Figure 1-3](#) below.



1. Extend the tilt-stand until its maximum reach



2. Detach the tilt-stand



4. Re-attach the tilt-stand to an upright position



3. Flip the tilt-stand over until this side of the stand is facing the multimeter as opposed to facing you

Figure 1-3 Tilt-stand at hanging position

The front panel at a glance



Figure 1-4 U1252B front panel

The rear panel at a glance




Figure 1-5 Rear panel

The rotary switch at a glance



Figure 1-6 Rotary switch

Table 1-1 Rotary switch description and functions

| No. | Description/Function |
|-----|---|
| 1 | Charge mode (U1252B only) or OFF |
| 2 | AC voltage |
| 3 | AC voltage, DC voltage or DC+AC voltage (U1252B only) |
| 4 | DC mV, AC mV, AC+DC mV (U1252B only) |
| 5 | Resistance (Ω), Continuity, and Conductance (nS) |
| 6 | Frequency counter (U1252B only) or Diode |
| 7 | Capacitance or Temperature |
| 8 | DC μ A, AC μ A, AC+DC μ A |
| 9 | DC mA, DC current, AC mA, AC current or AC+DC current |
| 10 | Square-wave output, Duty cycle, or Pulse width output (for U1252B) and OFF (for U1251B) |

The keypad at a glance





















The operation of each key is shown below. Pressing a key illuminates a related symbol on the display and emits a beep. Turning the rotary switch to another position resets the current operation of the key.

Figure 1-7 below shows the keypad of the U1252B. The **ms%** (Pulse width/Duty cycle), **Hz**, and frequency counter functions are only available on the U1252B.





Figure 1-7 U1252B keypad

Table 1-2 Keypad descriptions and functions

| Button | Function when pressed for less than 1 second | Function when pressed for more than 1 second |
|--|--|--|
| 1  |  acts as a toggle switch to turn backlight ON/OFF. Backlit automatically turns off after 30s (default) ^[1] . |  displays the battery capacity for 3 seconds. |
| 2  |  freezes the measured value. In Data Hold mode, press again to trigger hold of the next measured value. In Refresh Hold mode, reading updates automatically once reading is stable and count setting is exceeded ^[1] . |  enters Dynamic Recording mode. Press  again to scroll through Max, Min, Avg, and present readings (indicated by MAXMINAVG on display). |
| 3  |  saves displayed value as a reference to be subtracted from subsequent measurements. Press again to see the relative value that has been saved. |  enters 1 ms Peak Hold mode. Press  to scroll through Max and Min peak readings. |
| 4  |  scrolls through the measuring function(s) at a particular rotary switch position. |  enters Log Review mode. Press  to switch to manual or interval logging data. Press  or  to view first or last logged data respectively. Press  or  to scroll up or down logged data. Press  for more than 1 second to exit mode. |


1 Getting Started Tutorial


Table 1-2 Keypad descriptions and functions (continued)

| | | | |
|---|-------|---|--|
| 5 | Range | Range scrolls through available measuring ranges (except when rotary switch is set at  or at Hz [for U1252B] position) ^[2] . | Range sets to Auto Range mode. |
| 6 | Dual | Dual scrolls through available dual-combination displays (except when rotary switch is set at  or TEMP or Hz [for U1252B] position, or when meter is in 1 ms peak hold or dynamic recording mode) ^[3] . | Dual exits Hold, Null, Dynamic Recording, 1 ms Peak Hold and dual display modes. |
| 7 | Hz | enters Frequency Test mode for current or voltage measurements. Press Hz to scroll through frequency (Hz), duty cycle (%) and pulse width (ms) functions. In duty cycle (%) and pulse width (ms) tests, press Dual to switch to positive or negative pulse. | Hz enters logging mode. In manual data logging, press Hz to log data manually into memory. In automatic data logging, data logs automatically ^[1] . Press Hz for more than 1 second to exit auto data logging mode. |

Notes for keypad descriptions and functions:

1 See [Table 4-1](#) on page 77 for details of available options.

2 When rotary switch is at , press Range to switch to °C or °F display. When rotary switch is at Hz, press Range to switch to division of signal frequency by 1 or 100.

3 When rotary switch is at , ETC is ON by default. You may press Dual to disable ETC (Environment Temperature Compensation), **0°C** will appear on display. For pulse and duty cycle measurement, press Dual to switch trigger slope to positive or negative. When meter is in peak or dynamic-recording mode, press Dual to restart 1 ms peak hold or dynamic recording mode.

The display at a glance

To view the full display (with all segments illuminated), press and hold **Hold** button while turning the rotary switch from OFF to any non-OFF position. After you are done viewing the full display, press any button to resume normal functionality based on the rotary switch position. This is followed by a wake-up feature.

The meter will then enter power save mode once auto power off (APF) is enabled. To wake the meter up:

- 1 Turn the rotary switch to OFF position then ON again.
- 2 Press any button for rotary switch position that is not at square wave output position. (U1252B only)
- 3 To set the rotary switch at square wave out position, press only the Dual, Range and Hold buttons or turn the rotary switch to another position. (U1252B only)

The LCD signs are explained in the following tables.










Figure 1-8 Display symbols

Table 1-3 General display symbols

| LCD symbol | Description |
|------------|--|
| | Remote control |
| | Thermocouple types: (K-type) (J-type) |
| NULL | Null math function |
| | Diode / Audible continuity |
| | Audible continuity for resistance |
| | View mode for checking logged data |
| | Data logging indication |
| | Square wave output (U1252B only) |
| | <ul style="list-style-type: none"> Positive slope for pulse width (ms) and duty cycle (%) measurement Charging capacitor as capacitance measurement |
| | <ul style="list-style-type: none"> Negative slope for pulse width (ms) and duty cycle (%) measurement Discharging capacitor as capacitance measurement |
| | Low battery indication |
| Auto OFF | Auto power off enable |
| | Refresh (auto) Hold |
| TRIG | Trigger (manual) Hold |
| MAXMINAVG | Dynamic Recording mode: Present value on primary display |
| MAX | Dynamic Recording mode: Maximum value on primary display |
| MIN | Dynamic Recording mode: Minimum value on primary display |
| AVG | Dynamic Recording mode: Average value on primary display |
| MAX | 1 ms Peak Hold mode: Positive peak value on primary display |
| MIN | 1 ms Peak Hold mode: Negative peak value on primary display |






The primary display signs are explained below.

Table 1-4 Primary display symbols

| LCD symbol | Description |
|---|--|
| AUTO | Auto range |
|  | AC + DC |
|  | DC |
|  | AC |
|  | Polarity, digits, and decimal points for primary display |
| dBm | Decibel unit relative to 1 mW |
| dBV | Decibel unit relative to 1 V |
| MkHz | Frequency units: Hz, kHz, MHz |
| MkΩ | Resistance units: Ω, kΩ, MΩ |
| nS | Conductance unit |
| mV | Voltage units: mV, V |
| μmA | Current units: μA, mA, A |
| % | Duty cycle measurement |
| ms | Pulse width unit |
| μmF | Capacitance units: nF, μF, mF |
| °C | Celsius temperature unit |
| °F | Fahrenheit temperature unit |
|  | Percentage scale readout proportional to DC 0–20 mA |
|  | Percentage scale readout proportional to DC 4–20 mA |

The secondary display signs are explained below.

Table 1-5 Secondary display symbols







| LCD symbol | Description |
|---|--|
|  | AC + DC |
|  | DC |
|  | AC |
|  | Polarity, digits and decimal points for secondary display |
| kHz | Frequency units: Hz, kHz |
|  | No ambient temperature compensation, just thermocouple measurement |
| °C | Celsius ambient temperature unit |
| °F | Fahrenheit ambient temperature unit |
| mV | Voltage units: mV, V |
| μmA | Current units: μA, mA, A |
| s | Elapsed time unit: s (second) for Dynamic Recording and 1 ms Peak Hold modes |

The analog bar emulates the needle on an analog multimeter, without displaying the overshoot. When measuring peak or null adjustments and viewing fast-changing inputs, the bar graph provides a useful indication because it has quicker update rate for fast response applications.


The bar graph is not used for square wave output, frequency, duty cycle, pulse width, 4–20 mA% scale, 0–20 mA% scale and temperature measurements. When frequency, duty cycle and pulse width are indicated on the primary display during voltage or current measurement, the bar graph represents the voltage or current value. When 4–20 mA% scale or 0–20 mA% scale is indicated on the primary display, the bar graph represents the current value and not the percentage value.

The “+” or “-” sign is indicated when the positive or negative value has been measured or calculated. Each segment represents 2500 or 500 counts depending on the range indicated on the peak bar graph. See the table below.

Table 1-6 Analog bar range and counts

| Range | Counts/segments | Used for the function |
|---|-----------------|-----------------------|
|  | 2500 | V, Ω , Diode |
|  | 2500 | V, A, Ω |
|  | 2500 | V, A, Ω , nS |
|  | 500 | V, \rightarrow |
|  | 500 | \rightarrow |
|  | 500 | \rightarrow |

Selecting display with the Hz button

The frequency measurement feature helps to detect the presence of harmonic currents in neutral conductors and determines whether these neutral currents are the result of unbalanced phases or non-linear loads. Press  to access the frequency measurement mode for current or voltage measurements – voltage or current on the secondary



display and frequency on the primary display. Alternatively, pulse width (ms) or duty cycle (%) can appear on the primary display by pressing  again. This enables the simultaneous monitoring of real-time voltage and current, with frequency, duty cycle or pulse width. Voltage or current measurement resumes on the primary display after you press and hold  for more than 1 second.

Table 1-7 Selecting display with the Hz button


















| Rotary switch position (Function) | Primary Display | Secondary Display |
|--|------------------|-------------------|
|  V  V for U1252B (AC voltage) | Frequency (Hz) | AC V |
| | Pulse width (ms) | |
| | Duty cycle (%) | |
|  V for U1251B  V for U1252B (DC voltage) | Frequency (Hz) | DC V |
| | Pulse width (ms) | |
| | Duty cycle (%) | |
|  V for U1252B (AC + DC voltage) | Frequency (Hz) | AC + DC V |
| | Pulse width (ms) | |
| | Duty cycle (%) | |
|  mV (AC voltage) | Frequency (Hz) | AC mV |
| | Pulse width (ms) | |
| | Duty cycle (%) | |
|  mV (DC voltage) | Frequency (Hz) | DC mV |
| | Pulse width (ms) | |
| | Duty cycle (%) | |
|  mV (AC + DC voltage) | Frequency (Hz) | AC + DC mV |
| | Pulse width (ms) | |
| | Duty cycle (%) | |
|  A  (AC Current) | Frequency (Hz) | AC μ A |
| | Pulse width (ms) | |
| | Duty cycle (%) | |

Table 1-7 Selecting display with the Hz button (continued)

| | | |
|---|------------------|-----------------|
|  (DC current) | Frequency (Hz) | DC μ A |
| | Pulse width (ms) | |
| | Duty cycle (%) | |
|  (AC + DC current) [for U1252B] | Frequency (Hz) | AC + DC μ A |
| | Pulse width (ms) | |
| | Duty cycle (%) | |
|  (AC current) | Frequency (Hz) | AC mA or A |
| | Pulse width (ms) | |
| | Duty cycle (%) | |
|  (DC current) | Frequency (Hz) | DC mA or A |
| | Pulse width (ms) | |
| | Duty cycle (%) | |
|  (AC + DC current) [for U1252B] | Frequency (Hz) | AC + DC mA or A |
| | Pulse width (ms) | |
| | Duty cycle (%) | |
| Hz (Frequency counter) - press  to select frequency division by 1 [for U1252B] | Frequency (Hz) | - 1 - |
| | Pulse width (ms) | |
| | Duty cycle (%) | |
| Hz (Frequency counter) - press  to select frequency division by 100 [for U1252B] | Frequency (Hz) | - 100 - |

Selecting display with the Dual button











Press  to select different combinations of dual display. Normal single display resumes after you press and hold  for more than 1 second. See [Table 1-8](#) below.

Table 1-8 Selecting display with the Dual button

| Rotary switch position (Function) | Primary display | Secondary display |
|---|--|------------------------------|
|  (AC voltage) | AC V | Hz (AC coupling) |
| | dBm or dBV (select by pressing ) | AC V |
| | AC V | Ambient temperature °C or °F |
|  for U1252B (AC voltage) | AC V | Hz (AC coupling) |
| | dBm or dBV ^[1] | AC V |
| | AC V | DC V |
| | AC V | Ambient temperature °C or °F |
|  for U1251B/  for U1252B (DC voltage) | DC V | Hz (DC coupling) |
| | dBm or dBV ^[1] | DC V |
| | DC V | AC V [for U1252B] |
| | DC V | Ambient temperature °C or °F |
|  for U1252B (AC + DC voltage) | AC + DC V | Hz (AC coupling) |
| | dBm or dBV ^[1] | AC + DC V |
| | AC + DC V | AC V |
| | AC + DC V | DC V |
| | AC + DC V | Ambient temperature °C or °F |
|  (AC voltage) | AC mV | Hz (AC coupling) |
| | dBm or dBV ^[1] | AC mV |
| | AC mV | DC mV |
| | AC mV | Ambient temperature °C or °F |
|  (DC voltage) | DC mV | Hz (DC coupling) |
| | dBm or dBV ^[1] | DC mV |
| | DC mV | AC mV |
| | DC mV | Ambient temperature °C or °F |

Notes for selecting display with the Dual button:

- 1 Reading of dBm or dBV depends on the last review on AC V. If the last review is dBV, the following display will also remain in dBV.

Table 1-8 Selecting display with the Dual button (continued)










| | | |
|--|------------------|------------------------------|
|  mV (AC + DC voltage) [for U1252B] | AC + DC mV | Hz (AC coupling) |
| | dBm or dBV | AC + DC mV |
| | AC + DC mV | AC mV |
| | AC + DC mV | DC mV |
| | AC + DC mV | Ambient temperature °C or °F |
|  μA (DC current) | DC μA | Hz (DC coupling) |
| | DC μA | AC μA |
| | DC μA | Ambient temperature °C or °F |
|  μA (AC current) | AC μA | Hz (AC coupling) |
| | AC μA | DC μA |
| | AC μA | Ambient temperature °C or °F |
|  μA (AC + DC current) [for U1252B] | AC + DC μA | Hz (AC coupling) |
| | AC + DC μA | AC μA |
| | AC + DC μA | DC μA |
| | AC + DC μA | Ambient temperature °C or °F |
|  mA·A (DC current) | DC mA | Hz (DC coupling) |
| | DC mA | AC mA |
| | % (0–20 or 4–20) | DC mA |
| | DC mA | Ambient temperature °C or °F |
|  mA·A (AC current) | AC mA | Hz (AC coupling) |
| | AC mA | DC mA |
| | AC mA | Ambient temperature °C or °F |
|  mA·A (AC + DC current) [for U1252B] | AC + DC mA | Hz (AC coupling) |
| | AC + DC mA | AC mA |
| | AC + DC mA | DC mA |
| | AC + DC mA | Ambient temperature °C or °F |
|  mA·A (DC current) | DC A | Hz (DC coupling) |
| | DC A | AC A |
| | DC A | Ambient temperature °C or °F |

Table 1-8 Selecting display with the Dual button (continued)

| | | |
|--|-----------------|--|
|  (AC current) | AC A | Hz (AC coupling) |
| | AC A | DC A |
| | AC A | Ambient temperature °C or °F |
|  (AC + DC current) [for U1252B] | AC + DC A | Hz (AC coupling) |
| | AC + DC A | AC A |
| | AC + DC A | DC A |
| | AC + DC A | Ambient temperature °C or °F |
|  (Capacitance)  (Diode)/  (Resistance)/ nS (Conductance) | nF / V / Ω / nS | Ambient temperature °C or °F |
|  (Temperature) | °C (°F) | Ambient temperature °C or °F |
| | °C (°F) | Ambient temperature °C or °F / 0 °C compensation (select by pressing ) |

Selecting display with the Shift button

The table below shows selection of primary display, with respect to measuring function (rotary switch position), using the Shift button.

Table 1-9 Selecting display with the Shift button














| Rotary switch position (Function) | Primary Display |
|---|--|
|  (AC Voltage) | AC V |
| | dBm (in dual display mode) ^{[1][2]} |
| | dBV (in dual display mode) ^{[1][2]} |
|  V for U1251B | DC V |
|  V for U1252B (AC + DC Voltage) | DC V |
| | AC V |
| | AC + DC V |

Table 1-9 Selecting display with the Shift button

| | |
|---|--|
|  mV for U1252B (AC + DC Voltage) | DC mV |
| | AC mV |
| | AC + DC mV |
| Ω (Resistance) | Ω |
| |  Ω |
| | nS |
|  (Diode test and Frequency) | Diode |
| | Hz |
|  (Capacitance and Temperature) | Capacitance |
| | Temperature |
| μA  (AC Current) | DC μA |
| | AC μA |
| | AC + DC μA [for U1252B] |
| $\text{mA} \cdot \text{A}$  (DC Current) | DC mA |
| | AC mA |
| | AC + DC mA |
| | %(0–20 or 4–20) |
| $\text{mA} \cdot \text{A}$  (AC + DC Current) | DC A |
| | AC A |
| | AC + DC A [for U1252B] |
|  (Square wave output for U1252B) | Duty cycle (%) |
| | Pulse width (ms) |

Notes for selecting display with the Shift button:

- 1 Press  to switch between dBm and dBV measurement.
- 2 Press  for more than 1 second to return to AC V measurement only.

The terminals at a glance

WARNING

To avoid damaging the multimeter, do not exceed the input limit.



Figure 1-9 Connector terminals

Table 1-10 Terminal connections for different measuring functions

| Rotary switch position | Input terminals | | Overload protection |
|--|---------------------|-----|--|
| $\sim V$ $\sim V$ for U1252B $\equiv V$ for U1251B | Ω V mV | COM | 1000 V R.M.S. |
| $\sim mV$ | | | 1000 V R.M.S. for short circuit <0.3 A |
| Ω | | | |
| \rightarrow | | | |
| \rightarrow | | | |
| μA \sim $mA \cdot A$ \sim | μA . mA | COM | 440 mA / 1000 V 30 kA fast-acting fuse |
| $mA \cdot A$ \sim | A | COM | 11 A / 1000 V 30 kA fast-acting fuse |
| $\% \text{ OUT ms}$ for U1252B | $\% \text{ OUT ms}$ | COM | |
| \rightarrow CHG | \rightarrow CHG | COM | 440 mA / 1000 V fast-acting fuse |



2 Making Measurements

| | |
|--|----|
| Understanding The Measurement Instructions | 24 |
| Measuring Voltage | 24 |
| Measuring AC voltage | 25 |
| Measuring DC voltage | 26 |
| Measuring AC and DC Signals (U1252B only) | 28 |
| μ A & mA measurement | 29 |
| Percentage scale of 4 mA to 20 mA | 31 |
| A (ampere) measurement | 33 |
| Frequency Counter | 34 |
| Measuring Resistance, Conductance and Testing Continuity | 36 |
| Testing Diodes | 40 |
| Measuring Capacitance | 43 |
| Measuring Temperature | 45 |
| Alerts and Warning During Measurement | 49 |
| Overload alert | 49 |
| Input warning | 49 |
| Charge terminal alert | 50 |

This chapter contains information on how to make measurements using the U1251B and U1252B handheld digital multimeter.



Understanding The Measurement Instructions



When making measurements, follow the numerical steps labelled in the diagrams. Refer to [Table 2-1](#) below for a description of the steps.

Table 2-1 Numerical steps descriptions

| No. | Instructions |
|-----|---|
| 1 | Turn the rotary switch to the measurement option shown in the diagram |
| 2 | Connect the test leads into the input terminals shown in the diagram |
| 3 | Probe the test points |
| 4 | Read the results on the display |

Measuring Voltage

The U1251B and U1252B offer true-RMS readings for AC measurements that are accurate for sine waves, square waves, triangle waves, staircase waves, and other waveforms without any DC offset.

For AC with DC offset, use AC + DC measurement on  **V** or  **mV** rotary switch location. Applies only to U1252B.

WARNING

Ensure that the terminal connections are correct for that particular measurement before proceeding with the measurement. To avoid damaging the device, do not exceed the input limit.

Measuring AC voltage

Set up the multimeter to measure AC voltage as shown in Figure 2-1. Probe the test points and read the display.




Figure 2-1 Measuring AC voltage

NOTE

Press **Dual** to display frequency on the secondary display. See Table 1-8 of “Selecting display with the Dual button” on page 17 for a list of the different combinations available on the secondary display.

Measuring DC voltage

Set up the multimeter to measure DC voltage as shown in [Figure 2-2](#). Probe the test points and read the display.




Figure 2-2 Measuring DC voltage

CAUTION

- For measuring AC voltage signals with a DC offset, refer to the [“Measuring AC and DC Signals \(U1252B only\)”](#) on page 28.
- For measuring DC voltage from a mixed signal in DC measurement mode, ensure that the Filter is enabled (Refer to [“Setting the Filter”](#) on page 99).
- To avoid possible electric shock or personal injury, enable the Low Pass Filter to verify the presence of hazardous DC voltages. Displayed DC voltage values can be influenced by high frequency AC components and must be filtered to assure an accurate reading.

Measuring AC and DC Signals (U1252B only)






For better accuracy when measuring the DC offset of an AC voltage, measure the AC voltage first. Note the AC voltage range, then manually select a DC voltage range equal to or higher than the AC range. This procedure improves the accuracy of the DC measurement by ensuring that the input protection circuits are not activated.

Measuring Current

μA & mA measurement

Set up the multimeter to measure μA and mA as shown in [Figure 2-3](#). Probe the test points and read the display.

NOTE

- Press  if necessary to ensure $\overline{\text{---}}$ is shown on the display.
- For μA measurement, set the rotary switch to μA , and connect the positive test lead to $\mu\text{A.mA}$.
- For mA measurement, set the rotary switch to $\text{mA}\cdot\text{A}$ , and connect the positive test lead to $\mu\text{A.mA}$.
- For A (ampere) measurement, set the rotary switch to $\text{mA}\cdot\text{A}$ , and connect the positive test lead to **A**.
- Press  to display dual measurements. See [Table 1-8](#) of “[Selecting display with the Dual button](#)” on page 17 for a list of dual measurements available.

2 Making Measurements








Figure 2-3 Measuring μA and mA current

Percentage scale of 4 mA to 20 mA

Set up the multimeter to measure percentage scale as shown in Figure 2-4. Probe the test points and read the display.

NOTE

- Press  to select percentage scale display. Ensure that  or  is shown on the display.
- The percentage scale for 4 mA to 20 mA or 0 mA to 20 mA is calculated using its corresponding DC mA measurement. The U1251B and U1252B will automatically optimize the best resolution according to Table 2-2 below.
- Press  to change the measurement range.

The percentage scale for 4 mA to 20 mA or 0 mA to 20 mA is set to two ranges as follows:

Table 2-2 Percentage scale and measurement range

| Percentage scale (4 mA to 20 or 0 mA to 20 mA) Always auto range | DC mA auto or manual range |
|---|----------------------------|
| 999.99% | 50 mA, 500 mA |
| 9999.9% | |

2 Making Measurements




Figure 2-4 Measuring scale of 4-20 mA

A (ampere) measurement

Set up the multimeter to measure A (ampere) as shown in Figure 2-5. Probe the test points and read the display.

NOTE

Connect the red and black test leads to the 10 A input terminal **A** and **COM** respectively. The meter is set to A measurement automatically when the red test lead is plugged into the **A** terminal.




Figure 2-5 A (ampere) current measurement




Frequency Counter


WARNING

- Use the frequency counter for low voltage applications only. Never use the frequency counter for line power system.
 - For inputs more than 30 Vpp, you are required to use frequency measurement mode available under the current or voltage measurement instead of frequency counter.
-

Set up the multimeter to measure frequency as shown in Figure 2-6. Probe the test points and read the display.

NOTE

- Press  to select the Frequency counter (Hz) function. “-1-” on the secondary display means the input signal frequency is divided by 1. This allows signals of up to a maximum frequency of 985 kHz to be measured.
 - If the reading is unstable or is zero, press  to select the division of the input signal frequency by 100. This allows for a higher frequency range of up to 20 MHz to be measured.
 - The signal is out of range if the reading is still unstable after the above step.
 - While the secondary display shows “-1-”, you may scroll through the pulse width (ms), duty cycle (%) and frequency (Hz) measurements by pressing .
-



Measuring Resistance, Conductance and Testing Continuity

CAUTION

Disconnect the circuit power and discharge all high-voltage capacitors before measuring resistance to prevent any possible damage to the multimeter or the device under test.

Set up the multimeter to measure resistance as shown in Figure 2-7. Then probe the test points (by shunting the resistor) and read the display.




Figure 2-7 Measuring resistance


Press  to scroll through audible continuity, conductance and resistance tests as shown in [Figure 2-8](#).

Figure 2-8 Audible continuity, conductance, and resistance test.

Audible continuity

In the range of 0–500 Ω , the beeper will sound if the resistance value falls below 10 Ω . For other ranges, the beeper will sound if the resistance falls below the typical values indicated in [Table 2-3](#) below.

Table 2-3 Audible continuity measurement range

| Measurement range | Beeper sound threshold |
|-------------------|------------------------|
| 500.00 Ω | < 10 Ω |
| 5.0000 k Ω | < 100 Ω |
| 50.000 k Ω | < 1 k Ω |
| 500.00 k Ω | < 10 k Ω |
| 5.0000 M Ω | < 100 k Ω |
| 50.000 M Ω | < 1 M Ω |
| 500.00 M Ω | < 10 M Ω |

Conductance

Set up the multimeter to measure conductance as shown in [Figure 2-9](#). Probe the test points and read the display.

The conductance measurement enables the measurement of very high resistance of up to 100 G Ω .

As the high-resistance readings are susceptible to noise, you can capture the average readings by using the Dynamic Recording mode. Refer to the section “[Dynamic Recording](#)” on page 52 for more information.




Figure 2-9 Conductance measurement

Testing Diodes

CAUTION

Disconnect the circuit power and discharge all the high-voltage capacitors before testing the diodes to prevent any possible damage to the meter.

To test a diode, turn the power off to the circuit and remove the diode from the circuit. Set up the multimeter as shown in [Figure 2-10](#), then use the red probe lead on the positive terminal (anode) and use the black probe lead on the negative terminal (cathode) and read the display.

NOTE

- The cathode is the side with band(s).
 - The meter can display the diode's forward bias of up to approximately 2.1 V. A typical diode's forward bias is between the range of 0.3 V to 0.8 V.
-

Next, reverse the probes and measure the voltage across the diodes again as shown in [Figure 2-11](#) on page 42. The diode's test result is based on the following:

- The diode is considered good if the meter displays "OL" in reverse bias mode.
- The diode is considered shorted if the meter displays approximately 0 V in both forward and reverse bias modes, and the meter beeps continuously.
- The diode is considered open if the meter displays "OL" in both forward and reverse bias modes.





Figure 2-10 Measuring forward bias of diode

2 Making Measurements




Measuring Capacitance



CAUTION

Disconnect the circuit power and discharge all the high-voltage capacitors before measuring the capacitance to prevent any possible damage to the meter or the device under test. To confirm that the capacitors have discharged, use the DC voltage function.

The meter measures capacitance by charging the capacitor with a known current for a period of time, measuring the voltage and then calculating the capacitance. The larger the capacitor, the longer the charge time. Below are some tips for measuring capacitance:



- For measuring capacitance values greater than 10,000 μF , discharge the capacitor first, then select a suitable range for the measurement. This will speed up measuring time in order to obtain the correct capacitance value.
- For measuring smaller capacitance values, press  with the test leads open to subtract any residual capacitance from the meter or the leads.

NOTE

 means the capacitor is charging.  means the capacitor is discharging.

Set up the multimeter as shown in [Figure 2-12](#). Use the red probe lead on the positive terminal of the capacitor and the black probe lead on the negative terminal and read the display.

2 Making Measurements



Measuring Temperature


CAUTION

Do not bend the thermocouple leads at sharp angles. Repeated bending over a period of time may break the leads.

The bead type thermocouple probe is suitable for making temperature measurements between $-20\text{ }^{\circ}\text{C}$ to $200\text{ }^{\circ}\text{C}$ in PTFE compatible environments.

Do not use the bead-type thermocouple probe beyond the recommended operating temperature range. Do not immerse this thermocouple probe in liquids. For best results, use a thermocouple probe designed for each application – an immersion probe for liquid or gel and an air probe for air measurements.

Set up the multimeter to measure temperature as shown in [Figure 2-15](#) or observe the following steps:

- 1 Press  to select the temperature measurement.
- 2 Connect the miniature thermal probe into the non-compensation transfer adapter as shown in [Figure 2-13](#).
- 3 Connect the thermal probe with the adapter into the meter input terminals as shown in [Figure 2-14](#).
- 4 For best performance, place the meter in the operating environment for at least one hour to stabilize the unit to environment temperatures.
- 5 Clean the measurement surface and make sure the probe is securely touching the surface. Remember to disable the applied power.
- 6 When measuring above the ambient temperature, move the thermocouple along the surface until you get the highest temperature reading.
- 7 When measuring below ambient temperature, move the thermocouple along the surface until you get the lowest temperature reading.



2 Making Measurements

- 8 For a quick measurement, use the 0 °C compensation adapter to see the temperature variation of the thermocouple sensor. The 0 °C compensation adapter assists in measuring the relative temperature immediately.

Figure 2-13 Connecting the thermal probe into the non-compensation transfer adapter

Figure 2-14 Connecting the probe with adapter into the multimeter

If you are working in a constantly varying environment, where ambient temperatures are not constant, do the following:

- 1 Press  to select 0 °C compensation. This gives a quick measurement of the relative temperature.
- 2 Avoid contact between the thermocouple probe and the measurement surface.
- 3 After a constant reading is obtained, press  to set the reading as the relative reference temperature.
- 4 Touch the measurement surface with the thermocouple probe.
- 5 Read the display for the relative temperature.

2 Making Measurements




Figure 2-15 Surface temperature measurement

Alerts and Warning During Measurement

Overload alert

WARNING

For your safety, look out for this alert. When you are alerted, immediately remove the test leads from the measuring source.

The meter provides an overload alert for voltage measurements in both auto and manual range modes. The meter beeps periodically once the measuring voltage exceeds 1010 V. For your safety, please be aware of this alert.

Input warning

The meter sounds an alert beep when the test lead is inserted into the **A** input terminal but the rotary switch is not set to the corresponding **mA.A** location. The primary display indicates a flashing “**A-Err**” until the test lead is removed from the **A** input terminal. Refer to [Figure 2-16](#).







Figure 2-16 Input terminal warning

Charge terminal alert

The meter sounds an alert beep when the  **CHG** terminal detects a voltage level of more than 5 V and the rotary switch is not set to the corresponding  **CHG** location. The primary display indicates a flashing “Ch.Err” until the lead is removed from the  **CHG** input terminal. Refer to [Figure 2-17](#) below.




Figure 2-17 Charge terminal alert



3 Functions and Features

| | |
|---------------------------------|----|
| Dynamic Recording | 52 |
| Data Hold (Trigger Hold) | 54 |
| Refresh Hold | 55 |
| Null (Relative) | 57 |
| Decibel Display | 59 |
| 1 ms Peak Hold | 61 |
| Data Logging | 63 |
| Manual logging | 63 |
| Interval logging | 65 |
| Reviewing logged data | 67 |
| Square Wave Output (for U1252B) | 69 |
| Remote Communication | 73 |





This chapter contains information on the functions and features that are available for the U1251B and U1252B digital multimeter.




Dynamic Recording

The Dynamic Recording mode can be used to detect intermittent turn-on or turn-off voltage, current surges or to verify measurement performance without you being present during the process. While the readings are being recorded, you are free to perform other tasks.

The average reading is useful for smoothing out unstable inputs, estimating the percentage of time a circuit is operating and verifying circuit performance. The elapsed time is shown on the secondary display. The maximum time is 99999 seconds. When this maximum time is exceeded "OL" is shown on the display.

- 1 Press  for more than 1 second to enter Dynamic Recording mode. The meter is now in continuous mode or non-data hold (non-trigger) mode. "MAXMINAVG" and present value of measurement are displayed. The multimeter will beep when a new maximum or minimum value is recorded.
- 2 Press  to cycle through maximum, minimum, average, and present readings. The MAX, MIN, AVG, and MAXMINAVG indicators light up, corresponding to the displayed readings.
- 3 Press  or  for more than 1 second to exit Dynamic Recording mode.

NOTE

- Press  to restart the dynamic recording.
- The average value is the true average of all the measured values taken in the Dynamic Recording mode. If an overload is recorded, the averaging function will stop and the average value becomes "OL" (overload). **Auto OFF** is disabled in Dynamic Recording mode.




Figure 3-1 Dynamic recording mode operation

Data Hold (Trigger Hold)

The data hold function allows the user to freeze the displayed digital value.

- 1 Press **Hold** to freeze the displayed value and to enter the manual trigger mode. **TRIG HOLD** is displayed.
- 2 Press **Hold** again to freeze the next value being measured. **TRIG** flashes before the new value is updated on the display.
- 3 Press and hold **Hold** or **Dual** for more than 1 second to quit the data hold function.






Figure 3-2 Data hold mode operation

Refresh Hold

The Refresh Hold function allows you to hold the displayed value. The bar-graph is not held and will continue to reflect the instantaneous measured value. You can use the Setup mode to enable Refresh Hold mode when you are working with fluctuating values. This function will auto trigger or update the held value with a new measured value and emit a tone as a reminder.

- 1 Press  to enter Refresh Hold mode. The present value will be held and the **HOLD** symbol will appear.
- 2 It will be ready to hold a new measured value once the variation of measured values exceeds the variation count setting. While the multimeter is waiting for a new stable value, the **HOLD** symbol will flash.
- 3 The **HOLD** symbol will stop flashing once the new measured value is stable and the new value will be updated to the display. The symbol will remain on and the multimeter will emit a tone to remind you of this.
- 4 Press  again to quit the Refresh Hold function.







Figure 3-3 Refresh hold mode operation

NOTE

- For voltage and current measurements, the holding value will not be updated if the reading is below 500 counts.
- For resistance and diode measurements, the holding value will not be updated if the reading is in “OL” (open state).
- The holding value may not be updated when the reading does not reach a stable state for all measurements.

Null (Relative)

The Null function subtracts a stored value from the present measurement and displays the difference between the two.

- 1 Press  to store the displayed reading as the reference value to be subtracted from subsequent measurements and to set the display to zero. **NULL** is displayed.
- 2 Press  to see the stored reference value. **NULL** flashes for 3 seconds before the display returns to zero.
- 3 To exit this mode, press  while **NULL** is flashing on the display.

NOTE

- Null can be set for both auto and manual range settings, but not in the event of an overload.
 - When taking a resistance measurement and the meter reads a non-zero value due to the presence of test leads, use the Null function to adjust the display to zero.
 - When taking a DC voltage measurement, the thermal effect will influence the accuracy. Short the test leads and press Null once the displayed value is stable in order to zero out the display.
-




Figure 3-4 Null (relative) mode operation

Decibel Display





The dBm operation calculates the power delivered to a reference resistance relative to 1 mW and can be applied to DC V, AC V and AC + DC V measurements for decibel conversion. The voltage measurement is converted to dBm by using the following formula:

$$\text{dBm} = 10 \log_{10} \left[\frac{1000 \times (\text{measuring value})^2}{\text{reference impedance}} \right]$$


The reference resistance may be selected from 1~9999 Ω in Setup mode. The default value is 50 Ω .

The decibel of voltage is calculated with respect to 1 V. The equation for the voltage measurement is as follows:

$$\text{dBV} = 20 \log_{10} \text{Vin}$$

- 1 At the  V,  V or  mV rotary switch position, press  to scroll to the dBm measurement on the primary display. The secondary display indicates the AC voltage measurement.

NOTE

If the rotary switch is at the “~ V” position, press  to switch between the dBV and the dBm measurements. The dBm or the dBV measurements can be selected at the ACV position. The selection will be the reference for other voltage measurements.

- 2 Press  for more than 1 second to exit this mode.






Figure 3-5 dBm/dBV display mode operation



1 ms Peak Hold



The Peak Hold function allows the measurement of peak voltage for analysis of components such as power distribution transformers and power factor correction capacitors. The peak voltage obtained can be used to determine the crest factor:

Crest factor = Peak value/True RMS value

- 1 Press  for more than 1 second to toggle 1 ms Peak Hold mode ON / OFF.
- 2 Press  to scroll through maximum and minimum peak readings. **HOLD MAX** indicates the maximum peak, while **HOLD MIN** indicates the minimum peak.

NOTE

- If the reading is "**OL**", press  to change the measuring range and to re-start the peak-recording measurement.
- If you need to re-start the peak recording, press .

- 3 Press and hold  or  for more than 1 second to exit this mode.
- 4 According to the measurements shown in [Table 3-6](#) on page 62, the crest Factor will be $2.5048/1.768 = 1.416$.




Figure 3-6 1 ms peak hold mode operation

Data Logging

The data logging function provides the convenience of recording test data for future review or analysis. Since data is stored in nonvolatile memory, the data remains saved even if the multimeter is turned OFF or the battery is changed.

The two options offered are manual (hand) logging and interval (time) logging functions, which is determined in the Setup mode.



Data logging records the values on the primary display only.

NOTE

To use the data logging function, you will need to connect the multimeter to a PC using the U1173A IR-to-USB cable (purchased separately) and download the data logging software from Agilent's website. Please go to: <http://www.agilent.com/find/hhTechLib> to download the software.

Manual logging

Firstly, ensure that manual (hand) logging is specified in Setup mode.

- 1 Press  for more than 1 second to store the present value and function on the primary display to the non-volatile memory. The **LOG** and the logging index will be indicated. The logging index flashes on the secondary display for 3 seconds before returning to normal display.
- 2 Press and hold  again for the next value that you would like to save into the memory.




Figure 3-7 Hand (Manual) logging mode operation

NOTE

The maximum data that can be stored is 100 entries. When the 100 entries are filled, the secondary display indicates "FULL", as shown in Figure 3-8.





Figure 3-8 Full Log

Interval logging

Firstly, ensure that interval (time) logging is specified in Setup mode.

- 1 Press  for more than 1 second to store the present value and function on the primary display into the non-volatile memory. The **LOG** and the logging index will be indicated. The readings are automatically saved into the permanent memory at intervals set using the Setup mode.

NOTE

The maximum data that can be stored is 200 entries. When the 200 entries are filled, "FULL" is indicated on the secondary display.

- 2 Press  for more than 1 second to exit this mode.

NOTE

When interval (automatic) logging is enabled, all keypad operations are disabled, except for the Log function.












Figure 3-9 Interval (Automatic) logging mode operation

Reviewing logged data

- 1 Press  for more than 1 second to enter the Log Review mode. The last recorded entry and the last logging index are displayed.
- 2 Press  to switch between hand (manual) and interval (automatic) logging review mode.
- 3 Press  to ascend or  to descend through the logged data. Press  to select the first record and press  to select the last record for quick navigation.
- 4 Press  for more than 1 second at the respective Log Review mode to clear logged data.
- 5 Press  for more than 1 second to exit mode.
- 6 During the data review in either manual or interval logging mode, press **LOG** for more than one second to clear all the logged values.




Figure 3-10 Log review mode operation


Square Wave Output (for U1252B)


The square wave output function can be used to generate a PWM (pulse width modulation) output or provide a synchronous clock source (baud rate generator). You can also use this function to check and calibrate flow-meter displays, counters, tachometers, oscilloscopes, frequency converters, frequency transmitters, and other frequency input devices.

- 1 Turn the rotary switch to $\frac{\mu\text{V}}{\text{OUT ms}} \%$ position. The default display setting is 600 Hz on the secondary display and 50% duty cycle on the primary display.
- 2 Press \leftarrow or \rightarrow to scroll through the available frequencies (choose from the available 28 frequencies):

| Frequency (Hz) |
|--|
| 0.5, 1, 2, 5, 10, 15, 20, 25, 30, 40, 50, 60, 75, 80, 100, 120, 150, 200, 240, 300, 400, 480, 600, 800, 1200, 1600, 2400, 4800 |

NOTE

Pressing  is the same as pressing \rightarrow .

- 3 Press  to select the duty cycle (%) on the primary display.
- 4 Press \blacktriangle or \blacktriangledown to adjust the duty cycle. Duty cycle can be set for 256 steps and each step is 0.390625%. The display only indicates the best resolution with 0.001%.







Figure 3-11 Frequency adjustment for square wave output

- 5 Press  to select the pulse width (ms) on the primary display.
- 6 Press  or  to adjust the pulse width. The pulse width can be set for 256 steps and each step is $1 / (256 \times \text{Frequency})$. The display range automatically adjusts in the range of 9.9999~9999.9 ms.




Figure 3-12 Duty cycle adjustment for square wave output




Figure 3-13 Pulse width adjustment for square wave output

Remote Communication

The meter has a bi-directional (full duplex) communication capability that speeds data storing from the meter to the PC. To use this feature, you require the optional IR-USB cable, to be used with an application software downloadable from the Agilent Web site.

For details on performing PC to meter remote communication click on Help after launching the Agilent GUI Data Logger Software or refer to the [GUI Data Logger Quick Start Guide](#) (U1251-90023) for more information.





Figure 3-14 Cable connection for remote communication

3 Features and Functions



4 Changing The Default Setting


| | |
|---|----|
| Selecting Setup Mode | 76 |
| Setting Data Hold/Refresh Hold Mode | 80 |
| Setting Data Logging Mode | 81 |
| Setting Thermocouple Types (U1252B only) | 82 |
| Setting Reference Impedance for dBm Measurement | 83 |
| Setting Minimum Frequency Measurement | 84 |
| Setting Temperature Unit | 85 |
| Setting Auto Power Saving Mode | 87 |
| Setting Percentage (%) Scale Readout | 89 |
| Setting Beep Frequency | 90 |
| Setting Backlight Timer | 91 |
| Setting Baud Rate | 92 |
| Setting Parity Check | 93 |
| Setting Data Bit | 94 |
| Setting Echo Mode | 95 |
| Setting Print Mode | 96 |
| Returning to Default Factory Settings | 97 |
| Setting the Battery Voltage | 98 |
| Setting the Filter | 99 |

This chapter shows you how to change the default factory settings of the U1251B and U1252B and other available setting options.



Selecting Setup Mode

To enter the Setup mode, perform the following steps:

- 1 Turn the meter OFF.
- 2 From the OFF position, press and hold  while turning the rotary switch to any non-OFF position.

NOTE

When you hear a beep, the meter is in Setup mode and you can release



To change a menu item setting in Setup mode, perform the following steps:








- 1 Press  or  to scroll through the menu items.
- 2 Press  or  to scroll through the available settings. See [Table 4-1](#), “Available setting options in Setup mode,” for details of available options.
- 3 Press  to save changes. These parameters will remain in the non-volatile memory.
- 4 Press  for more than 1 second to exit Setup mode.

Table 4-1 Available setting options in Setup mode



| Menu item | | Available setting options | | Default factory setting |
|----------------------|-----------------|-------------------------------------|--|-------------------------|
| Display | Description | Display | Description | |
| rHoLd ^[1] | Refresh Hold | OFF | Enables Data Hold (manual trigger) | 500 |
| | | 100–1000 | Sets the variation count that determines Refresh Hold (auto trigger) | |
| FiLtE | DC filter | On, OFF | Enables DC filter when set to On | OFF |
| bAtt | Battery voltage | 7.2 V, 8.4 V | Selects battery voltage to either 7.2 V or 8.4 V | 7.2 V |
| rESEt | Reset | dEFAU | Enables the reset of factory settings by pressing and holding  for more than 1 second | dEFAU |
| Print | Print | On, OFF | Enables auto send of data to the PC continuously when set to On | OFF |
| ECHO | Echo | On, OFF | Enables the return of characters to the PC when set to On | OFF |
| dAtAb | Data bits | 7-bit, 8-bit | Sets the data bit length for the remote communication (remote control with PC) | 8-bit |
| PArY | Parity check | En, Odd, nOnE | Sets the even, odd or no parity check for the remote communication (remote control with PC) | nOnE |
| bAUd | Baud rate | 2400 Hz, 4800 Hz, 9600 Hz, 19200 Hz | Sets the baud rate for the remote communication (remote control with PC) | 9600 Hz |

4 Changing The Default Setting



Table 4-1 Available setting options in Setup mode (continued)

| Menu item | | Available setting options | | Default factory setting |
|-----------------------|---|----------------------------------|--|-------------------------|
| Display | Description | Display | Description | |
| b-Lit | Backlit display | 1–99 s ^[2] | Sets the timer for the auto turn-off for the backlit display | 30 s |
| | | OFF | Disables the auto turn-off for the backlit display | |
| bEEP | Frequency of beep sound of meter | 2400 Hz, 1200 Hz, 600 Hz, 300 Hz | Sets the frequency of the meter's beep sound | 2400 Hz |
| | | OFF | Disables the meter's beep sound | |
| PERnt | Percentage scale | 0–20 mA, 4–20 mA | Sets the % scale read-out | 4–20 mA |
| APF | Auto power off | 1–99 m ^[2] | Sets the timer for auto power off | 10 m |
| | | OFF | Disables auto power off | |
| FrEq | Minimum frequency that can be measured | 0.5 Hz, 1 Hz, 2 Hz, 5 Hz | Sets the minimum frequency that can be measured | 0.5 Hz |
| rEF | Reference impedance for dBm measurement | 1–9999 Ω ^[2] | Sets the reference impedance for dBm measurement | 50 Ω |
| t.CoUP ^[3] | Thermocouple | tYPE ^k | Sets the thermocouple type to K-type | tYPE ^k |
| | | tYPE ^J | Sets the thermocouple type to J-type | |
| d-LoG | Data logging | Hand | Enables manual data logging | Hand |
| | | 1–9999 s ^[2] | Sets the interval for automatic data logging | |

Table 4-1 Available setting options in Setup mode (continued)

| Menu item | | Available setting options | | Default factory setting |
|-----------|-------------|---------------------------|--|-------------------------|
| Display | Description | Display | Description | |
| tEMP [4] | Temperature | d-CF | Sets the temperature measurement to °C but pressing  swaps the display to °F | d-C |
| | | d-F | Sets the temperature measurement to °F | |
| | | d-FC | Sets the temperature measurement to °F but pressing  swaps display to °C | |
| | | d-C | Sets the temperature measurement to °C | |

Notes for setting options in Setup mode:

- 1 This is the first option displayed once the user enters Setup mode.
- 2 For b-Lit, APF, rEF and d-LoG menu items, the user can select the digit to be adjusted by pressing .
- 3 This menu option is only available for the U1252B.
- 4 To view the tEMP menu item, press  for more than 1 second.

Setting Data Hold/Refresh Hold Mode

- 1 Set OFF to enable the Data Hold mode (manual trigger by key or bus via the remote control).
- 2 Set the variation count within the 100~1000 range to enable the Refresh Hold mode (auto trigger). When the variation of the measuring value exceeds the setting of the variation count, the Refresh Hold will be ready to trigger.




Figure 4-1 Data hold/Refresh hold setup

Setting Data Logging Mode

- 1 Set to “Hand” to enable the manual data logging mode.
- 2 Set the interval within 0001–9999 seconds to enable interval (automatic) data logging mode.
- 3 Press and hold ◀ or ▶ for more than 1 second to switch between manual and interval data logging setup.




Figure 4-2 Data logging setup

Setting Thermocouple Types (U1252B only)

The thermocouple sensor types that can be selected are type K (default) or type J. Press ▲ or ▼ to switch between the J and the K type.



Figure 4-3 Thermocouple type setup

Setting Reference Impedance for dBm Measurement

The reference impedance can be set from 1 to 9999 Ω . The default value is 50 Ω .




Figure 4-4 Reference impedance for dBm measurement setup

Setting Minimum Frequency Measurement

The minimum frequency setup influences the measuring rates for frequency, duty cycle and pulse width. The typical measuring rate is based on the minimum frequency of 1 Hz.





Figure 4-5 Minimum frequency setup

Setting Temperature Unit

Four combination displays are available:

- Celsius only (°C on primary display) single display setting
- Celsius-Fahrenheit (d-CF) and Fahrenheit-Celsius (d-FC) dual display setting.

NOTE

Primary-Secondary Display can be swapped by pressing  .

- Fahrenheit only (°F on primary display) single display setting.

4 Changing The Default Setting




Figure 4-6 Temperature unit setup

Setting Auto Power Saving Mode

- The timer for APF (Auto Power OFF) can be set for the range of 1–99 minutes.
- To activate the meter after it has “auto powered-off”, turn the rotary switch to the OFF position. Then turn it back on again.
- **Auto OFF** will be shown on the display during subsequent measurements.

4 Changing The Default Setting




Figure 4-7 Auto power saving setup

Setting Percentage (%) Scale Readout

This setting converts the DC current measuring display to percentage (%) scale readout – 4–20 mA or 0–20 mA as proportional to 0~100%. The 25% scale readout represents DC 8 mA at 4–20 mA and DC 5 mA at 0–20 mA.




Figure 4-8 % scale readout setup

Setting Beep Frequency

The driving frequency can be set to 2400, 1200, 600, or 300Hz. "OFF" disables the beep.




Figure 4-9 Beep frequency setup

Setting Backlight Timer

- The timer can be set to 1–99 seconds. The backlight will turn off automatically after the set period.
- “OFF” disables turning off backlit automatically.




Figure 4-10 Backlit timer setup

Setting Baud Rate

Select the baud rate for remote control. The available settings are 2400, 4800, 9600, and 19200 Hz.




Figure 4-11 Baud rate setup remote control

Setting Parity Check

Select the parity check for remote control. It can be set to none, even, or odd bit.




Figure 4-12 Parity check setup

Setting Data Bit

Select the data bit for remote control. It can be set to either 8 or 7 bits.




Figure 4-13 Data bit setup for remote control

Setting Echo Mode

- Echo ON enables the return of characters to the PC in remote communication.
- Echo OFF disables the return of characters to the PC.



Figure 4-14 Echo mode setup for remote control

Setting Print Mode

Print ON enables the printing of measured data to the PC when the measuring cycle is completed. In this mode, the meter automatically sends the newest data to the host continuously but does not accept any commands from the host. **Remote** flashes during the Print operation.





Figure 4-15 Print mode setup for remote control

Returning to Default Factory Settings

- Press  for more than 1 second to reset to the default factory settings all menu options except the Temperature setting.
- The Reset menu item automatically reverts to Refresh Hold menu item after reset has taken place.




Figure 4-16 Reset setup

Setting the Battery Voltage

Battery type for the multimeter can be set to either 7.2 V or 8.4 V.




Figure 4-17 Battery voltage selection

Setting the Filter

This setting is used to filter AC signals in DC measuring paths. The DC filter is set to “ON” by default.




Figure 4-18 DC filter

NOTE

- When the DC filter is enabled, the measurement speed may decrease during DC voltage measurement.
- During AC or Hz measurement (on primary or secondary display), DC filter will be automatically disabled.
- For firmware version 2.17 and below, the Filter function is switched off by default. Customers are strongly advised to update their products to the latest firmware version to take advantage of the latest features and measurement improvements.

4 Changing The Default Setting

Table 4-2 Filter defaults

| Parameter | Firmware version | Default setting |
|-----------|------------------|-----------------|
| FiLtEr | 2.17 and below | oFF |
| | 2.18 and above | oN |



5 Maintenance

| | |
|----------------------------|-----|
| Introduction | 102 |
| General maintenance | 102 |
| Battery replacement | 102 |
| Storage considerations | 104 |
| Charging the battery | 105 |
| Fuse checking procedure | 112 |
| Replacing the fuse | 114 |
| Troubleshooting | 116 |
| Replaceable Parts | 117 |
| To order replaceable parts | 117 |

This chapter will go through how to troubleshoot the handheld digital multimeter if any problems arise.



Introduction

CAUTION

Any repair or service which is not covered in this manual should only be performed by qualified personnel.

General maintenance

WARNING

Ensure that the terminal connections are correct for that particular measurement before proceeding. To avoid damaging the device, do not exceed the input limit.

Besides the above hazard, dirt, or moisture in the terminals can distort readings. The steps for cleaning are as follows:


- 1 Turn the meter off and remove the test leads.
- 2 Turn the meter over and shake out any dirt that may have accumulated in the terminals.
- 3 Wipe the case with a damp cloth and a mild detergent – do not use abrasives or solvents. Wipe the contacts in each terminal with a clean swab dipped in alcohol.

Battery replacement

The meter is powered by a 9 V Ni-MH rechargeable battery, 8.4 V nominal voltage. Use only the specified type (refer to [Figure 5-1](#)). To ensure that the correct battery type is used, replace the battery immediately when the low battery sign flashes. If your meter has the rechargeable battery type, refer to the section “[Charging the battery](#)” on page 105.

The steps for battery replacement are the next page:

- 1 At the rear panel, turn the screw on the battery cover from the LOCK to the OPEN position (counterclockwise).



- 2 Slide down the battery cover.
- 3 Lift the battery cover up.
- 4 Replace the specified battery.
- 5 Reverse the above steps to close the cover.

NOTE

List of compatible batteries for the Agilent U1251B :

- 9 V Alkaline non-chargeable battery (ANSI/NEDA 1604A or IEC 6LR61)
- 9 V Carbon-zinc non-chargeable battery (ANSI/NEDA 1604D or IEC6F22)

NOTE

List of compatible batteries for the Agilent U1252B :

- 9 V size 300 mAH Ni-MH rechargeable battery, 7.2 V nominal voltage
 - 9 V size 250 mAH Ni-MH rechargeable battery, 8.4 V nominal voltage
 - 9 V Alkaline non-chargeable battery (ANSI/NEDA 1604A or IEC 6LR61)
 - 9 V Carbon-zinc non-chargeable battery (ANSI/NEDA 1604D or IEC6F22)
-




Figure 5-1 9 V rectangular battery

Storage considerations

CAUTION

To avoid instrument damage from battery leakage:

- Always remove dead batteries immediately.
 - It is recommended that the battery is removed and stored separately if the multimeter is to be unused for long periods of time.
-

After the first charge, it is recommended that you fully charge the battery periodically, even when it is not in use. This is because the Ni-MH rechargeable battery pack may drain with time.

NOTE


The performance of the rechargeable battery may degrade with time.

Charging the battery

WARNING

Never discharge the battery by shorting it or by reverse polarity in any subjects. Make sure the battery is the rechargeable type before charging it. Never rotate the rotary switch when the battery is being charged as DC at 24 V is being applied to the charging terminals.

CAUTION



- Do not rotate the rotary switch from OFF CHG position when charging the battery.
- Perform battery charging only with a 9 V Ni-MH rechargeable battery (7.2 V nominal voltage) or 9 V size Ni-MH rechargeable battery (8.4 V nominal voltage)
- Disconnect test leads from all the terminals when charging.
- Ensure proper insertion of battery in the multimeter and follow the correct polarity.

NOTE

For the battery charger, the mains supply voltage should not fluctuate by plus or minus 10%.

A new rechargeable battery comes in a discharged condition and must be charged before use. Upon initial use (or after a prolonged storage period), the battery may require three to four charge/discharge cycles before achieving maximum capacity. To discharge, simply run the multimeter under the battery's power until it shuts down or the low battery warning appears.

Use the specified 24 V DC adaptor to charge the battery. Remember never to turn the rotary switch of the meter when its battery is being charged. Use the following steps to charge the battery:



- 1 Disconnect the test leads from the meter.
- 2 Turn the rotary switch to the  ^{OFF}CHG position. Connect the power cord to the DC adaptor.
- 3 Plug the Red (+)/ Black (-) banana terminals of the DC adaptor to the  CHG and the “COM” terminals respectively. The DC adaptor can be replaced with a DC power supply in order to set the 24 V DC output and the over current limitation to a value more than 0.5 A. Ensure that the polarity of the connection is correct.
- 4 The primary display will show “bAt” and the ‘SbY’ will be shown on the secondary display and a short beep will sound to remind you whether you need to charge the battery. Press **SHIFT** to start charging the battery, or the meter will automatically start the self-test after the 24 V supply is applied. It is recommended that you do not charge if the battery’s capacity is over 90%.

Table 5-1 Battery voltage and corresponding percentage of charges in standby and charging modes

| Condition | Battery voltage | Proportional percentage |
|---------------|-----------------|-------------------------|
| Trickle (SBY) | 7.0 V to 9.6 V | 0% to 100% |
| Charging | 7.2 V to 10.0 V | 0% to 100% |




Figure 5-2 Battery capacity display as trickle

- 5 After pressing **SHIFT** or when the self-test starts, the meter performs a self-test to check if the battery in the meter is the rechargeable type. The self-test takes about 2 to 3 minutes. Avoid pressing any button during the self-test. A message is displayed as shown in [Figure 5-3](#).




Figure 5-3 Self-test

Table 5-2 Error messages

| Error | Error message |
|--|---|
| <p>OL</p> <ol style="list-style-type: none"> 1 No battery inside 2 Faulty battery 3 Battery is fully charged | <p>The image shows a digital display with an error message. At the top, the code 'OL' is displayed in a large, pixelated font. Below it, the word 'BAT' is displayed in a similar font. At the bottom of the display, there is a battery level indicator consisting of a series of vertical bars of increasing height from left to right, with markings for 0, 5, and 100. A plus sign is on the left and a battery icon is on the right.</p> |
| Error | Error message |

Table 5-2 Error messages (continued)

| | |
|---|--|
| <p>C-Err</p> <ol style="list-style-type: none"> 1 If charging battery more than 12 V or less than 5 V 2 In 3 minutes, if the battery voltage does not go upwards then charge error |  |
|---|--|

NOTE

- If the **OL** message appears while the battery is inside, do not charge the battery.
- If the **C-Err** message appears, check if the battery is the specified type. Use the battery as specified in this manual. Ensure that the battery is the correct rechargeable type before charging it again. After replacing with the correct rechargeable battery, press Shift to perform the self-test again. If the C-Err message reappears, replace with a new battery.

- 6 The smart charging mode will start if the meter passes the self-test. The charging time is limited to not more than 220 minutes. The secondary display will count down the charging time. During charging, no buttons can be pressed. The error message may appear during charging to alert the user of any overcharging of the battery.






Figure 5-4 Charging mode

- 7 The charge end message (C-End) appears on the secondary display once charging is completed. The trickle charging current is provided to maintain the battery capacity. The flashing signs of  and  appear to show the trickle state.
- 8 Remove the DC adapter when the C-End message appears on the secondary display. Do not turn the rotary switch before removing the adapter from the terminals.




Figure 5-5 Charge end and trickle state




Figure 5-6 Battery charging procedure

Fuse checking procedure

It is recommended that you check the fuses of the multimeter before using it. Follow the instructions below to test the fuses inside the multimeter. Refer to Figure 5-8 for the respective positions of Fuse 1 and Fuse 2.

- 1 Set the rotary switch to $nS \rightarrow \Omega$.
- 2 Connect the red test lead to the input terminal $\Omega \rightarrow V \rightarrow mV$.




Figure 5-7 Fuse checking procedures


- 3 To test Fuse 1, place the tip of the test probe on the right half of input terminal . Ensure that the probe tip touches the metal inside the input terminal, as shown in the figure above.
- 4 To test Fuse 2, place and touch the tip of the test probe on the right half of input terminal **A**. Ensure that the probe tip touches the metal inside the input terminal.
- 5 Observe the reading on the instrument's display. Refer to [Table 5-3](#) below for the possible readings that could appear).
- 6 Replace the fuse when **OL** is displayed.

Table 5-3 Measurement readings for fuse checking

| Current input terminal | Fuse | Fuse rating | Fuse OK (approximately) | Replace fuse |
|-----------------------------|------|---------------|-------------------------|--------------|
| | | | Displayed readings | |
| $\mu\text{A}\cdot\text{mA}$ | 1 | 440 mA/1000 V | 6.2 M Ω | OL |
| A | 2 | 11 A/1000 V | 0.06 Ω | OL |

Replacing the fuse

NOTE


This manual provides only the fuse replacement procedures, but not the fuse replacement markings.

Follow the procedures below to replace the fuse.

- 1** Turn the meter off and disconnect the test leads from the external equipment. Make sure to remove the adaptor.
- 2** Wear clean/dry gloves and do not touch any other component except the fuse and plastic parts. The current calibration is considered shunt only, so do not recalibrate the meter after replacing the fuse.
- 3** Remove the battery cover compartment to replace the fuse.
- 4** Loosen the three screws on the bottom case and remove the cover.
- 5** Loosen the two screws on the top corners to lift the circuit board.
- 6** Gently remove the defective fuse by prying one end of the fuse loose and removing it out of the fuse bracket.
- 7** Replace with a new fuse of the same size and rating. Make sure the new fuse is centered in the fuse holder.
- 8** Ensure that the rotary switch on the top case and the circuit board switch stay on the OFF position.
- 9** Then re-fasten the circuit board and the bottom cover.
- 10** Refer to the table below for the part number, rate, and size of the fuses.

Table 5-4 Fuse specifications

| Fuse | Agilent part number | Rating | Size | Type |
|------|---------------------|-------------|---------------|----------------|
| 1 | 2110-1400 | 440mA/1000V | 10 mm x 35 mm | Fast blow Fuse |
| 2 | 2110-1402 | 11A/1000V | 10 mm x 38 mm | |

**Figure 5-8** Fuse replacement

Troubleshooting

WARNING

To avoid electrical shock, do not perform any service on the device unless you are qualified to do so.

If the instrument fails to operate, check the battery and the test leads. Replace them if necessary. And if the instrument still does not function, check the operating procedures in this manual. When servicing, use only specified replacement parts. [Table 5-5](#) below will assist you to identify some basic problems and their solutions.

Table 5-5 Basic troubleshooting procedures

| Malfunction | Troubleshooting procedure |
|---|--|
| No LCD display after power ON | <ul style="list-style-type: none"> • Check the battery. Charge or replace it. |
| No beeper tone | <ul style="list-style-type: none"> • Check the setup mode to verify if the beeper is set to OFF. Then select the desired driving frequency. |
| Fail on current measurement | <ul style="list-style-type: none"> • Check the fuse. |
| No charging indication ^[1] | <ul style="list-style-type: none"> • Check 440 mA fuse. • Check the external adapter to verify if the output is DC 24 V and the adapter is plugged into the charging terminals completely. • Line power voltage (100 V~240 V AC 50 Hz/ 60 Hz). |
| Battery life very short after full charge/Battery not able to charge after prolong storage period | <ul style="list-style-type: none"> • Check if the correct rechargeable battery is used. • Check if the correct nominal voltage level (7.2 V or 8.4 V) is selected in the battery setting at Setup Mode. • Try to charge and discharge for two or three cycles in order to maintain the battery's highest capacity. • NOTE: The performance of the rechargeable battery may degrade with time. |
| Fail on Remote control | <ul style="list-style-type: none"> • Check that the optical side of the cable is connected to the meter and the text side of the cover is up. • Check the baud rate, parity, Data bit, Stop bit (default is 9600, n, 8, 1) • Driver install for IR-USB. |

Notes for basic troubleshooting procedures table:

1 Never turn the rotary switch of the multimeter from the OFF position when it is charging.

Replaceable Parts

This section contains information for ordering replacement parts for your instrument. You can find the instrument support part list at Agilent's Test & Measurement Parts Catalog at: <http://www.agilent.com/find/parts>


This parts list includes a brief description of each part with applicable Agilent part number.

To order replaceable parts

You can order replaceable parts from Agilent using the Agilent part number. Note that not all parts listed are available as field-replaceable parts.

To order replaceable parts from Agilent, do the following:

- 1** Contact your nearest Agilent Sales Office or Service Center.
- 2** Identify the parts by the Agilent part number shown in the support parts list.
- 3** Provide the instrument model number and serial number.



6 Performance Tests and Calibration

| | |
|---|-----|
| Calibration Overview | 120 |
| Closed-case electronic calibration | 120 |
| Agilent Technologies calibration services | 120 |
| Calibration interval | 121 |
| Adjustment is recommended | 121 |
| Recommended Test Equipment | 122 |
| Basic Operating Test | 123 |
| Backlit test | 123 |
| Testing the display | 123 |
| Current terminal test | 124 |
| Charge terminal alert test | 125 |
| Test Considerations | 126 |
| Calibration Security | 127 |
| Performance Verification Tests | 128 |
| Unsecuring the instrument for calibration | 136 |
| Calibration Process | 139 |
| Using the front panel for adjustments | 140 |
| Adjustments Consideration | 141 |
| Valid adjustment input values | 142 |
| Adjustment Procedure | 143 |
| Finishing the Adjustment | 150 |
| To Read the Calibration Count | 150 |
| Calibration Errors | 151 |

This chapter contains the performance test procedures and the adjustment procedure.



Calibration Overview

This manual contains procedures to verify the instrument's performance and adjustment (calibration).

The performance test procedures allow you to verify that the handheld digital multimeter is operating within its published specifications. The adjustment procedures ensure that the multimeter remains within its specifications until the next calibration.

NOTE

Make sure you have read the “[Test Considerations](#)” on page 126 before calibrating the instrument.

Closed-case electronic calibration

This instrument features closed-case electronic calibration. No internal mechanical adjustments are required. The instrument calculates correction factors based upon the input reference value you set. The new correction factors are stored in the nonvolatile memory until the next calibration adjustment is performed. The nonvolatile EEPROM calibration memory is retained even when the power is switched off.

Agilent Technologies calibration services

When your instrument is due for calibration, contact your local Agilent Service Center to enquire about recalibration services.

Calibration interval

A 1-year interval is adequate for most applications. Accuracy specifications are warranted only if adjustment is made at regular calibration intervals. Accuracy specifications are not warranted beyond the 1-year calibration interval. Agilent does not recommend extending calibration intervals beyond 2 years for any application.

Adjustment is recommended

Specifications are only guaranteed within the period stated from the last adjustment. Agilent recommends that readjustment should be performed during the calibration process for best performance. This will ensure that the U1251B/U1252B will remain within the specifications for the next calibration interval. This criterion for the re-adjustment provides the best long-term stability.

Performance data are measured during the Performance Verification Tests but this does not guarantee that the instrument will remain within these limits unless the adjustments are performed.

Refer to the section [“To Read the Calibration Count”](#) on page 150 and verify that all the adjustments have been performed.

Recommended Test Equipment

The test equipment recommended for the performance verification and adjustment procedures is listed below. If the exact instrument is not available, substitute calibration standards of equivalent accuracy.

A suggested alternative method would be to use the Agilent 3458A 8½ – Digit Digital Multimeter to measure less accurate yet stable sources. The output value measured from the source can be entered into the instrument as the target calibration value.

Table 6-1 Recommended Test Equipment

| Application | Recommended equipment | Recommended accuracy requirements |
|-------------------|--|-----------------------------------|
| DC Voltage | Fluke 5520A | <1/5 instrument 1 year spec |
| DC Current | Fluke 5520A | <1/5 instrument 1 year spec |
| Resistance | Fluke 5520A | <1/5 instrument 1 year spec |
| AC Voltage | Fluke 5520A | <1/5 instrument 1 year spec |
| AC Current | Fluke 5520A | <1/5 instrument 1 year spec |
| Frequency | Agilent 33250A | <1/5 instrument 1 year spec |
| Capacitance | Fluke 5520A | <1/5 instrument 1 year spec |
| Duty Cycle | Fluke 5520A | <1/5 instrument 1 year spec |
| Nanosiemens | Fluke 5520A | <1/5 instrument 1 year spec |
| Diode | Fluke 5520A | <1/5 instrument 1 year spec |
| Frequency Counter | Agilent 33250A | <1/5 instrument 1 year spec |
| Temperature | Fluke 5520A | <1/5 instrument 1 year spec |
| Square Wave | Agilent 53131A and Agilent 34401A | <1/5 instrument 1 year spec |
| Short | Shorting Plug - Dual banana plug with copper wire short between 2 terminal | — |

Basic Operating Test

The Basic Operating Test is to test the basic operability of the instrument. Repair is required if the instrument fails the Basic Operating Test.

Backlit test

Press the Bat button to test the backlight. It will momentarily toggle backlit ON and OFF.

Testing the display

Press the Hold button and turn on the meter to view all segments of the display. Compare the display with the example in [Table 6-1](#).




Figure 6-1 LCD display

Current terminal test

This test determines if the input warning of the current terminal test is functioning properly.

The meter sounds an alert beep when the test lead is inserted into the A terminal but the rotary switch is not set to mA.A function. The primary display will indicate “A-Err” as shown in [Figure 6-2](#). The primary display will keep flashing unless the test lead is removed from “A” terminal.

NOTE

Before conducting this test, make sure the beep function is not disabled in setup.




Figure 6-2 Input warning

Charge terminal alert test

This test determines if the charge terminal alert is operating properly.




The meter sounds an alert when the CHG terminal detects a voltage level of more than 5 V and the rotary switch is not set to the OFF position. The meter sounds an alert beep and the primary display flashes the “Ch.Err” until the lead is removed from the CHG terminal.



Figure 6-3 Charge terminal alert

NOTE

Before conducting this test, make sure the beep function is not disabled at setup.

Test Considerations

Long test leads can also act as antennas which may pick up AC signals.

For optimum performance, all procedures should comply with the following recommendations:

- Ensure that the calibration ambient temperature is stable and is between 18 °C and 28 °C. Ideally the calibration should be performed at $23\text{ °C} \pm 1\text{ °C}$.
- Ensure that the ambient relative humidity is less than 80%.
- Allow a warm-up period of five minutes.
- Use shielded twisted pair PTFE-insulated cables to reduce settling and noise errors. Keep the input cables as short as possible.

Calibration Security

The calibration security code prevents accidental or unauthorized adjustments to the instrument. When you first receive your instrument, it is secured. Before you can adjust the instrument, you must unsecure it by entering the correct security code (see [“Unsecuring the instrument for calibration”](#) on page 136).

The security code is set to 1234 when the instrument is shipped from the factory. This code is stored in nonvolatile memory, and does not change when power is turned off.

The security code may contain up to 4 numeric characters.

NOTE

You can unsecure the instrument from the front panel. The security code can only be changed from the front panel after the instrument has been unsecured.

See [“To unsecure the instrument without the security code”](#) on page 138 if you forget your security code.

Performance Verification Tests

Use the Performance Verification Tests to verify the measurement performance of the instrument. The performance verification tests use the instrument's specifications listed in the U1251B/U1252B Data Sheet.




The performance verification tests are recommended as acceptance tests when you first receive the instrument. The acceptance test results should be compared against the one year test limits. After acceptance, you should repeat the performance verification tests at every calibration interval.

NOTE






Make sure you have read the "[Test Considerations](#)" on page 126 before doing the performance verification tests.



Perform the verification test steps in the following Table 6-2:

Table 6-2 Verification Test








| Step | Test Function | Range | 5520A Output | Error from nominal 1 year | |
|--------|---|----------------|-----------------------------------|---------------------------|------------|
| | | | | U1251B | U1252B |
| 1 | Turn the rotary switch to the  V position ^[1] | 5 V | 5 V, 1 kHz | ± 32.5 mV | ± 22.5 mV |
| | | | 4.5 V, 10 kHz | ± 169.5 mV | ± 71.5 mV |
| | | | 4.5 V, 20 kHz | N/A | ± 169.5 mV |
| | | | 4.5 V, 30 kHz | ± 169.5 mV | N/A |
| | | | 4.5 V, 100 kHz | N/A | ± 169.5 mV |
| | | 50 V | 50 V, 1 kHz | ± 325 mV | ± 225 mV |
| | | | 45 V, 10 kHz | ± 1.695 V | ± 715 mV |
| | | | 45 V, 20 kHz | N/A | ± 1.695 V |
| | | | 45 V, 30 kHz | ± 1.695 V | N/A |
| | | | 45 V, 100 kHz | N/A | ± 1.695 V |
| 500 V | 500 V, 1 kHz | ± 3.25 V | ± 2.25 V | | |
| 1000 V | 1000 V, 1 kHz | ± 10 V | ± 8.0 V | | |
| 2 | Press  button to go to frequency mode | 9.9999 kHz | 0.48 V, 1 kHz | ± 500 mHz | ± 500 mHz |
| 3 | Press  button to go to Duty Cycle mode | 0.01% – 99.99% | 5.0 Vpp @ 50%, Square Wave, 50 Hz | ± 0.315% | ± 0.315% |






6 Performance Tests and Calibration

| Step | Test Function | Range | 5520A Output | Error from nominal 1 year | |
|-----------|---|---------|----------------|---------------------------|------------------------|
| | | | | U1251B | U1252B |
| 4 | Turn the rotary switch to  V position (for model U1252B), to  V position (for model U1251B) | 5 V | 5 V | ± 2 mV | ± 1.75 mV |
| | | 50 V | 50 V | ± 20 mV | ± 17.5 mV |
| | | 500 V | 500 V | ± 200 mV | ± 200 mV |
| | | 1000 V | 1000 V | ± 800 mV | ± 800 mV |
| 5 | Press  button to go to the  V mode ^[1] | 5 V | 5 V, 1 kHz | N/A | ± 22.5 mV |
| | | | 5 V, 10 kHz | N/A | ± 79.0 mV |
| | | | 4.5 V, 20 kHz | N/A | ± 169.5 mV |
| | | | 4.5 V, 100 kHz | N/A | ± 169.5 mV |
| | | 50 V | 50 V, 1 kHz | N/A | ± 225 mV |
| | | | 50 V, 10 kHz | N/A | ± 790 mV |
| | | | 45 V, 20 kHz | N/A | ± 1.695 V |
| | | | 45 V, 100 kHz | N/A | ± 1.695 V |
| 500 V | 500 V, 1 kHz | N/A | ± 2.25 V | | |
| 1000 V | 1000 V, 1 kHz | N/A | ± 8.0 V | | |
| 6 | Turn the rotary switch to the  mV position | 50 mV | 50 mV | ± 75 μV ^[2] | ± 75 μV ^[2] |
| | | 500 mV | 500 mV | ± 0.2 mV | ± 0.175 mV |
| | | | - 500 mV | ± 0.2 mV | ± 0.175 mV |
| | | 1000 mV | 1000 mV | ± 0.8 mV | ± 0.75 mV |
| - 1000 mV | ± 0.8 mV | | ± 0.75 mV | | |






| Step | Test Function | Range | 5520A Output | Error from nominal 1 year | |
|------|--|---------|------------------|---------------------------|------------|
| | | | | U1251B | U1252B |
| 7 | Press  button to go to the  mV mode ^[1] | 50 mV | 50 mV, 1 kHz | ± 0.34 mV | ± 0.24 mV |
| | | | 50 mV, 10 kHz | ± 0.86 mV | ± 0.415 mV |
| | | | 45 mV, 20 kHz | N/A | ± 1.695 mV |
| | | | 50 mV, 30 kHz | ± 0.86 mV | N/A |
| | | | 45 mV, 100 kHz | N/A | ± 1.695 mV |
| | | 500 mV | 500 mV, 45 Hz | ± 3.25 mV | ± 2.25 mV |
| | | | 500 mV, 1 kHz | ± 3.25 mV | ± 2.25 mV |
| | | | 500 mV, 10 kHz | ± 8.6 mV | ± 4.15 mV |
| | | | 450 mV, 20 kHz | N/A | ± 16.95 mV |
| | | | 500 mV, 30 kHz | ± 8.6 mV | N/A |
| | | | 450 mV, 100 kHz | N/A | ± 16.95 mV |
| | | 1000 mV | 1000 mV, 1 kHz | ± 8.5 mV | ± 6.5 mV |
| | | | 1000 mV, 10 kHz | ± 47 mV | ± 11.5 mV |
| | | | 1000 mV, 20 kHz | N/A | ± 11.5 mV |
| | | | 1000 mV, 30 kHz | ± 47mV | N/A |
| | | | 1000 mV, 100 kHz | N/A | ± 47.0 mV |

6 Performance Tests and Calibration

| Step | Test Function | Range | 5520A Output | Error from nominal 1 year | |
|------|--|------------------------------|-----------------------|--|--|
| | | | | U1251B | U1252B |
| 8 | Turn the rotary switch to the Ω position | 500 Ω | 500 Ω | $\pm 500 \text{ m}\Omega$ ^[3] | $\pm 350 \text{ m}\Omega$ ^[3] |
| | | 5 k Ω | 5 k Ω | $\pm 4.5 \Omega$ ^[3] | $\pm 3 \Omega$ ^[3] |
| | | 50 k Ω | 50 k Ω | $\pm 45 \Omega$ | $\pm 30 \Omega$ |
| | | 500 k Ω | 500 k Ω | $\pm 450 \Omega$ | $\pm 300 \Omega$ |
| | | 5 M Ω | 5 M Ω | $\pm 10.5 \text{ k}\Omega$ | $\pm 8 \text{ k}\Omega$ |
| | | 50 M Ω ^[4] | 50 M Ω | $\pm 0.510 \text{ M}\Omega$ | $\pm 0.505 \text{ M}\Omega$ |
| | | 500 M Ω | 450 M Ω | N/A | $\pm 36.1 \text{ M}\Omega$ |
| 9 | Press  button to go to ns mode | 500 nS ^[5] | 50 nS | $\pm 0.7 \text{ nS}$ | $\pm 0.6 \text{ nS}$ |
| 10 | Turn the rotary switch to the Hz/  position (for model U1252B), to  position (for model U1251B) | Diode | 1 V | $\pm 1 \text{ mV}$ | $\pm 1 \text{ mV}$ |
| | | | 33250A Output | | |
| 11 | Press  button to go to frequency counter mode ^[6] | 999.99 kHz | 200 mVrms, 100 kHz | N/A | $\pm 52 \text{ Hz}$ |
| 12 | Press  button to go to frequency counter mode divide by 100 | 99.999 MHz | 600 mVrms, 10 MHz | N/A | $\pm 5.2 \text{ kHz}$ |
| | | | 5520A Output | | |
| 13 | Turn the rotary switch to the  /  position ^[7] | 10.000 nF | 10.000 nF | $\pm 0.108 \text{ nF}$ | $\pm 0.108 \text{ nF}$ |
| | | 100.00 nF | 100.00 nF | $\pm 1.05 \text{ nF}$ | $\pm 1.05 \text{ nF}$ |
| | | 1000.0 nF | 1000.0 nF | $\pm 10.5 \text{ nF}$ | $\pm 10.5 \text{ nF}$ |
| | | 10.000 μF | 10.000 μF | $\pm 0.105 \mu\text{F}$ | $\pm 0.105 \mu\text{F}$ |
| | | 100.00 μF | 100.00 μF | $\pm 1.05 \mu\text{F}$ | $\pm 1.05 \mu\text{F}$ |

| Step | Test Function | Range | 5520A Output | Error from nominal 1 year | |
|--|---|---|---|--|--|
| | | | | U1251B | U1252B |
| | | 1000.0 μF | 1000.0 μF | $\pm 10.5 \mu\text{F}$ | $\pm 10.5 \mu\text{F}$ |
| | | 10.00 mF | 10.00 mF | $\pm 0.105 \text{ mF}$ | $\pm 0.105 \text{ mF}$ |
| | | 100.00 mF | 10.00 mF | $\pm 0.4 \text{ mF}$ | $\pm 0.4 \text{ mF}$ |
| 14 | Press  button to go to I mode ^{[8][13]} | -200 $^{\circ}\text{C}$ until 1372 $^{\circ}\text{C}$ | 0 $^{\circ}\text{C}$ 100 $^{\circ}\text{C}$ | $\pm 3 \text{ }^{\circ}\text{C}$ $\pm 3.3 \text{ }^{\circ}\text{C}$ | $\pm 3 \text{ }^{\circ}\text{C}$ $\pm 3.3 \text{ }^{\circ}\text{C}$ |
| 15 | Turn the rotary switch to the μA  position | 500 μA | 500 μA | $\pm 0.55 \mu\text{A}$ ^[9] | $\pm 0.3 \mu\text{A}$ ^[9] |
| | | 5000 μA | 5000 μA | $\pm 5.5 \mu\text{A}$ ^[9] | $\pm 3 \mu\text{A}$ ^[9] |
| 16 | Press  button to go to $\sim \mu\text{A}$ mode ^[1] | 500 μA | 500 μA , 1 kHz | $\pm 4.2 \mu\text{A}$ | $\pm 3.7 \mu\text{A}$ |
| | | | 500 μA , 20 kHz | $\pm 15.8 \mu\text{A}$ | $\pm 3.95 \mu\text{A}$ |
| | | 5000 μA | 5000 μA , 1 kHz 5000 μA , 20 kHz | $\pm 42 \mu\text{A}$ $\pm 0.156 \text{ mA}$ | $\pm 37.0 \mu\text{A}$ $\pm 39.5 \mu\text{A}$ |
| 17 | Turn the rotary switch to the $\text{mA} \cdot \text{A}$  position | 50 mA | 50 mA | $\pm 0.105 \text{ mA}$ ^[9] | $\pm 80 \mu\text{A}$ ^[9] |
| | | 440 mA | 400 mA | $\pm 0.93 \text{ mA}$ ^[9] | $\pm 0.71 \text{ mA}$ ^[9] |
| 18 | Press  button to go to $\sim \text{mA}$ mode ^[1] | 50 mA | 50 mA, 1 kHz | $\pm 0.42 \text{ mA}$ | $\pm 0.37 \text{ mA}$ |
| | | | 50 mA, 20 kHz | $\pm 1.56 \text{ mA}$ | $\pm 0.395 \text{ mA}$ |
| | | 440 mA | 400 mA, 45 Hz 400 mA, 1 kHz | $\pm 3.4 \text{ mA}$ $\pm 3.4 \text{ mA}$ | $\pm 3.0 \text{ mA}$ $\pm 3.0 \text{ mA}$ |
| Caution: Connect the calibrator to handheld multimeter's A and COM terminals before applying 5A and 10A | | | | | |
| | | 5 A | 5 A | $\pm 16 \text{ mA}$ | $\pm 16 \text{ mA}$ |
| | | 10 A ^[10] | 10 A | $\pm 40 \text{ mA}$ | $\pm 35 \text{ mA}$ |

6 Performance Tests and Calibration

| Step | Test Function | Range | 5520A Output | Error from nominal 1 year | |
|------|---|---------------------------|-------------------|---------------------------|--------------------------|
| | | | | U1251B | U1252B |
| 19 | Press  button to go to  A mode | 5 A | 5 A, 1 kHz | ± 42 mA | ± 37 mA |
| | | 3A | 3 A, 5 kHz | ± 96 mA | ± 96 mA |
| | | 10 A ^[11] | 10 A, 1 kHz | ± 100 mA | ± 90 mA |
| | | Square Wave Output | Use 53131A | | |
| 20 | Turn the rotary switch to the  % OUT ms position | 120 Hz @ 50% | | N/A | ± 26 mHz |
| | | 4800 Hz @ 50% | | N/A | ± 260 mHz |
| |  % OUT ms Duty Cycle | 100 Hz @ 50% | | N/A | ± 0.398% ^[12] |
| | | 100 Hz @ 25% | | N/A | ± 0.398% ^[12] |
| | | 100 Hz @ 75% | | N/A | ± 0.398% ^[12] |
| | | | Use 34410A | | |
| |  % OUT ms Amplitude | 4800 Hz @ 99.609% | | N/A | ± 0.2V |

Notes for verification test:





- 1 The additional error to be added as frequency > 20 kHz and signal input < 10% of range: 300 counts of LSD per kHz.
- 2 The accuracy could be 0.05% + 10, always use relative function to zero thermal effect (short test leads) before measuring the signal.
- 3 The accuracy of 500 Ω and 5 kΩ is specified after the Null function.
- 4 For range of 50 MΩ/500 MΩ, the RH is specified for < 60%.
- 5 The accuracy is specified for < 50 nS and after Null function as open test lead.
- 6 All frequency counters are susceptible to error when measuring low voltage, low-frequency signals. Shielding inputs from external noise pickup is critical for minimizing measurement errors.
- 7 Use the Null mode to zero residual.
- 8 The accuracy does not include the tolerance of the thermocouple probe. The thermal sensor plugged into the meter should be placed in the operating environment for at least an hour. Use the Null function to reduce the thermal effect.
- 9 Always use relative function to zero the thermal effect with open test lead before measuring the signal. If you do not use Relation function, add 20 digits for accuracy purposes.




- 10** 10 A continuous, and additional 0.5% to specified accuracy when measuring a signal greater than 10 A~20 A for 30 seconds maximum. After measured current for > 10 A, to cool down the meter for twice the measuring time you applied before low current measurement.
- 11** The current can be measuring from 2.5 A to 10 A continuous, and the additional of 0.5% to specified accuracy as measure the signal greater than 10 A~20 A for 30 seconds maximum. After measured current for > 10 A, to cool down the meter for 2 times of measuring time you applied before low current measurement.
- 12** For signal frequency greater than 1 kHz, additional 0.1% per kHz to be added to accuracy.
- 13** Ensure that the ambient temperature is stable within ± 1 °C. Make sure that the multimeter is placed in a controlled environment for at least 1 hour. Keep the multimeter away from any ventilation exit. Do not touch the thermocouple test lead after connecting it to the calibrator. Allow the connection to stabilize for at least another 15 minutes before performing the measurement.

Unsecuring the instrument for calibration







Before you can adjust the instrument, you must unsecure it by entering the correct security code. The security code is set to 1234 when the instrument is shipped from the factory. The security code is stored in nonvolatile memory, and does not change when power is off.

To Unsecure the Instrument from the Front Panel

- 4 Turn the rotary switch to $\sim V$.
- 5 Press  and  button simultaneously to enter the Calibration Security Code entry mode.
- 6 The primary display shows 5555 and the secondary display show SECUR.
- 7 Use the editing keys  and  to step each character in the code.

Use the  and  to select each character.
- 8 Press  (Save) when done.
- 9 If the correct security code is entered, the secondary display will show PASS.

To change the instrument calibration security code from the front panel









- 1 When the multimeter is in the unsecured mode, press  for more than 1 second to enter the Calibration Security Code setting mode.
- 2 The factory default calibration security code 1234 will be displayed on the primary display.
- 3 Use the editing keys  and  to step each character in the code.
- 4 Use the  and  to change each character in the code.
- 5 Press  (Save) to store the new calibration security code.
- 6 If the new calibration security code has been successfully stored, the secondary display will show PASS.

To unsecure the instrument without the security code

To unsecure the instrument without the correct security code, follow the steps below.

NOTE

If you do not have a record of the security code, you can try 1234 (the factory default code) using the front panel.

- 1 Record the last 4 digits of the multimeter's serial number.
- 2 Turn the rotary switch to $\sim V$.
- 3 Press  and  simultaneously to enter the Calibration Security Code entry mode.
The primary display shows 5555 and the secondary display shows SECUR.
- 4 Press  for more than 1 second to enter the Set Default Security Code mode. The secondary display shows SEr.no and the primary display shows 5555.
- 5 Use the editing keys  and  to step each character in the code.
- 6 Use  and  to select each character.
- 7 Set the code, same as the last 4 digits of the instrument's serial number.
- 8 Press  (Save) to confirm the entry.
- 9 If the 4 digits entered are correct, the secondary display will show PASS.

Now you can use 1234 as the security code. If you want to enter a new security code, see [“To change the instrument calibration security code from the front panel”](#) on page 137. Make sure you record the new security code.

Calibration Process

To complete a full instrument calibration use following general procedures:

- 1 Read “[Test Considerations](#)” on page 126.
- 2 Perform the verification tests to characterize the instrument (incoming data).
- 3 Unsecure the instrument for calibration (see “[Calibration Security](#)” on page 127).
- 4 Perform the adjustment procedures (see “[Adjustments Consideration](#)” on page 141).
- 5 Secure the instrument against calibration.
- 6 Note the new security code and calibration count in the instrument's maintenance records.

NOTE

Make sure to quit the Adjustment Mode before turning off the instrument.

Using the front panel for adjustments






This section describes the procedures to perform adjustments from the front panel.

Selecting the Adjustment Mode

To unsecure the instrument, see “Unsecuring the instrument for calibration” on page 136 or “To unsecure the instrument without the security code” on page 138. Once unsecured, the reference value will be indicated on the primary display.

Entering Adjustment Values

Use the following adjustment procedure to enter an input calibration value from the front panel:

- 1 Use the edit keys  and  to select each digit in the primary display.
- 2 Use the  and the  arrow keys to advance through the digits 0 through 9.
- 3 Press  when done to start calibration.

Adjustments Consideration

You will need a test input cable, a connectors set, and a Shorting Plug to adjust the instrument.

NOTE

After each adjustment, the secondary display briefly shows PASS. If the calibration fails, the handheld multimeter sounds a beep, and an error number is shown in the secondary display. Calibration error messages are described on [page 151](#). In the event of a calibration failure, correct the problem and repeat the procedure.

Adjustments for each function should be performed only in the order shown below.

- 1 Allow the instrument to warm up and stabilize for 5 minutes before performing the adjustments.
- 2 Ensure that during the adjustments, the low battery indicator does not appear. Replace the batteries as soon as possible to avoid false reading.
- 3 Consider the thermal effects as you are connecting test leads to the calibrator and handheld multimeter. It is recommended to wait for one minute before you begin the calibration after connecting the test leads.
- 4 During ambient temperature adjustment, be sure to turn on the instrument for at least 1 hour with the K-type thermocouple connected between the instrument and the calibration source.









CAUTION

Never turn off the instrument during an adjustment. This may delete the calibration memory for the present function.

Valid adjustment input values

Adjustment can be accomplished using the following input values below.

Table 6-3 Valid adjustment input values


| Function | Range | Valid Amplitude Input Values |
|--|---|---|
|  V | 5 V, 50 V, 500 V, 1000 V | 0.9 to 1.1 x Full Scale |
|  V (for U1251B) | 5 V, 50 V, 500 V, 1000 V | 0.9 to 1.1 x Full Scale |
|  V (for U1252B) | 5 V, 50 V, 500 V, 1000 V | 0.9 to 1.1 x Full Scale |
|  mV | 50 mV, 500 mV, 1000 mV | 0.9 to 1.1 x Full Scale |
| μA  | 500 μA , 5000 μA | 0.9 to 1.1 x Full Scale |
| $\text{mA} \cdot \text{A}$  | 50 mA, 440 mA, 5 A, 10 A | 0.9 to 1.1 x Full Scale |
| Ω | 500 Ω , 5k Ω , 50 k Ω , 500 k Ω , 5M Ω , 50 M Ω | 0.9 to 1.1 x Full Scale |
|  | Diode | 0.9 to 1.1 x Full Scale |
|  | 10 nF, 100 nF, 1000 nF, 10 μF , 100 μF , 1000 μF , 10 mF / 0 °C | Make sure to provide 0 °C with ambient compensation |



Adjustment Procedure

Review the sections “[Test Considerations](#)” on page 126 and “[Adjustments Consideration](#)” on page 141 before proceeding with this procedure.

- 1 Turn the rotary switch to “Test Function” position as shown in the adjustment table.
- 2 After unsecuring the instrument, the instrument goes into the adjustment mode. (See “[Unsecuring the instrument for calibration](#)” on page 136)


NOTE

The instrument will be in the adjustment mode, unless you press Shift and  simultaneously to exit the adjustment mode.

- 3 The primary display will show the reference value of the Cal Item.
- 4 Configure each Cal Item.
- 5 Use the  and the  arrow keys to select the Cal Range.
- 6 Apply the input signal shown in the Input column of the table. The bar graph will display the Input reading. There is no bar graph display for temperature adjustment.

NOTE

Always complete the tests in the same order as shown in the appropriate table.

- 7 Enter the actual applied input (see “[Entering Adjustment Values](#)” on page 140).
- 8 Press  to start the adjustment. The CAL flashes in the secondary display to indicate that the calibration is in progress.




For an adjustment that is successful, the secondary display will briefly show PASS. An adjustment failure is indicated by a long beep and a calibration error number appears in the secondary display. The primary display remains at the current Cal Item. Check the input value, range, function, and entered adjustment value to fix the problem. Repeat the adjustment procedure.




- 9 Repeat steps 1 through 8 for each adjustment point.
- 10 Verify the adjustments using the “[Performance Verification Tests](#)” on page 128 and [Table](#) .


NOTE









For serial numbers below MY51530001, the 10 kHz input frequency is applied to those marked with an asterisk (*)





Table 6-4 Adjustment table

| Step | Test Function | Cal Range | Input | Cal Item | |
|------|---|-----------|---|----------|----------|
| | | | | U1251B | U1252B |
| 1 | Turn the rotary switch to the  V position | 5 V | 0.3 V, 1 kHz | 0.3000 V | 0.3000 V |
| | | | 3 V, 1 kHz | 3.0000 V | 3.0000 V |
| | | | 3 V, 20 kHz * | 3.0000 V | 3.0000 V |
| | | 50 V | 3 V, 1 kHz | 03.000 V | 03.000 V |
| | | | 30 V, 1 kHz | 30.000 V | 30.000 V |
| | | | 30 V, 20 kHz * | 3.0000 V | 30.000 V |
| | | 500 V | 30 V, 1 kHz | 030.00 V | 030.00 V |
| | | | 300 V, 1 kHz | 300.00 V | 300.00 V |
| | | | 300 V, 20 kHz * | 3.0000 V | 300.00 V |
| | | 1000 V | 30 V, 1 kHz | 0030.0 V | 0030.0 V |
| | | | 300 V, 1 kHz | 0300.0 V | 0300.0 V |
| | | | 300 V, 20 kHz * | 3.0000 V | 0300.0 V |
| 2 | Turn the rotary switch to  V position (for model U1252B), to  V position (for model U1251B) | Short | Dual Banana Plug with copper wire short between 2 terminals | SHort | SHort |
| | | 5 V | 3 V | 3.0000 V | 3.0000 V |
| | | 50 V | 30 V | 30.000 V | 30.000 V |
| | | 500 V | 300 V | 300.00 V | 300.00 V |
| | | 1000 V | 1000 V | 1000.0 V | 1000.0 V |

| Step | Test Function | Cal Range | Input | Cal Item | |
|------|--|-----------|---|-----------|-----------|
| | | | | U1251B | U1252B |
| 3 | Press  button to go to the  V mode | 5 V | 0.3 V, 1 kHz | N/A | 0.3000 V |
| | | | 3 V, 1 kHz | N/A | 3.0000 V |
| | | | 3 V, 20 kHz * | N/A | 3.0000 V |
| | | 50 V | 3 V, 1 kHz | N/A | 03.000 V |
| | | | 30 V, 1 kHz | N/A | 30.000 V |
| | | | 30 V, 20 kHz * | N/A | 30.000 V |
| | | 500 V | 30 V, 1 kHz | N/A | 030.00 V |
| | | | 300 V, 1 kHz | N/A | 300.00 V |
| | | | 300 V, 20 kHz * | N/A | 300.00 V |
| | | 1000 V | 30 V, 1 kHz | N/A | 0030.0 V |
| | | | 300 V, 1 kHz | N/A | 0300.0 V |
| | | | 300 V, 20 kHz * | N/A | 0300.0 V |
| 4 | Turn the rotary switch to the  mV position | Short | Dual banana plug with copper wire short between 2 terminals | SHort | SHort |
| | | 50 mV | 30 mV | 30.000 mV | 30.000 mV |
| | | 500 mV | 300 mV | 300.00 mV | 300.00 mV |
| | | 1000 mV | 1000 mV | 1000.0 mV | 1000.0 mV |

| Step | Test Function | Cal Range | Input | Cal Item | |
|--------------|--|-----------------|---|-------------------|-------------------|
| | | | | U1251B | U1252B |
| 5 | Press  button to go to the \sim mV mode | 50 mV | 3 mV, 1 kHz | 03.000 mV | 03.000 mV |
| | | | 30 mV, 1 kHz | 30.000 mV | 30.000 mV |
| | | | 30 mV, 20 kHz * | 30.000 mV | 30.000 mV |
| | | 500 mV | 30 mV, 1 kHz | 030.00 mV | 030.00 mV |
| | | | 300 mV, 1 kHz | 300.00 mV | 300.00 mV |
| | | | 300 mV, 20 kHz * | 30.000 mV | 300.00 mV |
| | | 1000 mV | 30 mV, 1 kHz | 0030.0 mV | 0030.0 mV |
| | | | 1000 mV, 1 kHz | 1000.0 mV | 1000.0 mV |
| | | | 1000 mV, 20 kHz* | 30.000 mV | 1000.0 mV |
| 6 | Turn the rotary switch to the Ω position ^[1] | Short | Dual Banana Plug with copper wire short between 2 terminals | SHort | SHort |
| | | 50 M Ω | Input terminal open (remove any test leads and Short Plugs from the input terminal) | oPEn | oPEn |
| | | | 10 M Ω | 10.000 M Ω | 10.000 M Ω |
| | | 5 M Ω | 3 M Ω | 3.0000 M Ω | 3.0000 M Ω |
| | | 500 k Ω | 300 k Ω | 300.00 k Ω | 300.00 k Ω |
| | | 50 k Ω | 30 k Ω | 30.000 k Ω | 30.000 k Ω |
| | | 5 k Ω | 3k Ω | 3.0000 k Ω | 3.0000 k Ω |
| 500 Ω | 300 Ω | 300.00 Ω | 300.00 Ω | | |



| Step | Test Function | Cal Range | Input | Cal Item | |
|---------|--|-----------|---|-----------|-----------|
| | | | | U1251B | U1252B |
| 7 | Turn the rotary switch to the Hz/  position (for model U1252B), to  position (for model U1251B) | Short | Dual banana shorting plug with copper wire | SHORT | SHORT |
| | | 2 V | 2 V | 2.0000 V | 2.0000 V |
| 8 | Turn the rotary switch to the  /  position | Open | Input terminal open (remove any test leads and Short Plugs from the input terminal) | oPEn | oPEn |
| | | 10 nF | 3 nF | 03.000 nF | 03.000 nF |
| | | | 10 nF | 10.000 nF | 10.000 nF |
| | | 100 nF | 10 nF | 010.00 nF | 010.00 nF |
| | | | 100 nF | 100.00 nF | 100.00 nF |
| | | 1000 nF | 100 nF | 0100.0 nF | 0100.0 nF |
| | | | 1000 nF | 1000.0 nF | 1000.0 nF |
| | | 10 μF | 10 μF | 10.000 μF | 10.000 μF |
| 100 μF | 100 μF | 100.00 μF | 100.00 μF | | |
| 1000 μF | 1000 μF | 1000.0 μF | 1000.0 μF | | |
| 10 mF | 10 mF | 10.000 mF | 10.000 mF | | |
| 9 | Press  button to go to  mode ^[2] | N/A | 0 °C | 0000.0 °C | 0000.0 °C |
| 10 | Turn the rotary switch to the   position | OPEN | Input terminal open (remove any test leads and Short Plugs from the input terminal) | oPEn | oPEn |
| | | 500 μA | 300 μA | 300.00 μA | 300.00 μA |
| | | 5000 μA | 3000 μA | 3000.0 μA | 3000.0 μA |

| Step | Test Function | Cal Range | Input | Cal Item | |
|--|--|--------------|---|----------------------------------|----------------------------------|
| | | | | U1251B | U1252B |
| 11 | Press  button to go to ~ μ A mode | 500 μ A | 30 μ A, 1 kHz 300 μ A, 1 kHz | 030.00 μ A 300.00 μ A | 030.00 μ A 300.00 μ A |
| | | 5000 μ A | 300 μ A, 1 kHz 3000 μ A, 1 kHz | 0300.0 μ A 3000.0 μ A | 0300.0 μ A 3000.0 μ A |
| 12 | Turn the Rotary Switch to the mA ·A  position | Open | Input terminal open (remove any test leads and Short Plugs from the input terminal) | oPEn | oPEn |
| | | 50 mA | 30 mA | 30.000 mA | 30.000 mA |
| | | 440 mA | 300 mA | 300.00 mA | 300.00 mA |
| Move the test lead from μA.mA and COM terminal to A and COM terminal | | | | | |
| Caution: Connect the calibrator to handheld multimeter's A and COM terminals before applying 3A and 10A | | | | | |
| | | 5 A | 3 A | 3.0000 A | 3.0000 A |
| | | 10 A | 10 A | 10.000 A | 10.000 A |
| Move the test lead from A and COM terminal to μA.mA and COM terminal | | | | | |
| 13 | Press  button to go to ~ mA mode | 50 mA | 3 mA, 1 kHz 30 mA, 1 kHz | 03.000 mA 30.000 mA | 03.000 mA 30.000 mA |
| | | 440 mA | 30 mA, 1 kHz 300 mA, 1 kHz | 030.00 mA 300.00 mA | 030.00 mA 300.00 mA |
| Move the test lead from μA.mA and COM terminal to A and COM terminal | | | | | |
| Caution: Connect the calibrator to handheld multimeter's A and COM terminals before applying 3A and 10A | | | | | |
| 14 | Press  button to go to ~ A mode | 5 A | 0.3 A, 1 kHz 3 A, 1 kHz | 0.3000 A 3.0000 A | 0.3000 A 3.0000 A |
| | | 10 A | 3 A, 1 kHz 10 A, 1 kHz | 3.0000 A 10.000 A | 3.0000 A 10.000 A |

Notes for adjustment table:

- 1 Be sure to recalibrate “Short” using the dual banana plug with copper wire after performing calibration for resistance.
- 2 Ensure the multimeter is turned on and stabilized for at least 60 minutes, with the K-type thermocouple connected between the multimeter and the calibrator output terminal.

Finishing the Adjustment

- 1 Remove all the shorting plugs and connectors from the instrument.
- 2 Record the new Calibration Count.
- 3 Press  and  simultaneously to exit the Adjustment Mode. Power off and on again. The instrument will then be secured.

To Read the Calibration Count



You can query the instrument to determine how many calibrations have been performed.

NOTE

Your instrument was calibrated before it left the factory.

When you receive your instrument, read the count to determine its initial value.

The count value increases by one for each calibration point, and a complete calibration will increase the value by many counts. The calibration count increments up to a maximum of 65535 after which it is set at 0. The calibration count can be read from the front panel after the instrument has been unsecured. Use the following procedure to read the calibration count from the front panel.


- 1 Press  Adjustment Mode. The primary display shows the calibration count.
- 2 Take note of the count.
- 3 Press  again to exit the calibration count mode.

Calibration Errors

The following errors indicate failures that may occur during a calibration.

Table 6-5 Calibration error codes and their respective meanings

| Error Code | Description |
|------------|--|
| 200 | Calibration error: Calibration mode is secured |
| 002 | Calibration error: Secure code invalid |
| 003 | Calibration error: Serial number code invalid |
| 004 | Calibration error: Calibration aborted |
| 005 | Calibration error: Value out of range |
| 006 | Calibration error: Signal measurement out of range |
| 007 | Calibration error: Frequency out of range |
| 008 | EEPROM write failure |



7 Specifications

| | |
|---|-----|
| Product Characteristics | 154 |
| Measurement Category | 157 |
| Measurement category definition | 157 |
| Specification Assumptions | 158 |
| Electrical Specifications | 158 |
| DC Specifications | 158 |
| AC Specifications | 161 |
| AC+DC Specifications for U1252B | 163 |
| Capacitance Specifications | 164 |
| Temperature Specifications | 164 |
| Frequency Specifications | 165 |
| Duty Cycle and Pulse Width Specifications | 165 |
| Frequency Sensitivity Specifications | 166 |
| Peak Hold Specifications | 168 |
| Frequency Counter Specifications for U1252B | 168 |
| Square Wave Output for U1252B | 169 |
| Operating Specifications | 171 |
| Display update rate (approximate) | 171 |
| Input impedance | 172 |

This chapter lists the product characteristics, specification assumptions and the specifications of the U1251B and U1252B digital multimeters.



Product Characteristics

POWER SUPPLY

Battery type:

- 9 V size Ni-MH rechargeable battery, 7.2 V nominal voltage
- 9 V size Ni-MH rechargeable battery, 8.4 V nominal voltage
- 9 V Alkaline battery (ANSI/NEDA 1604A or IEC 6LR61)
- 9 V Carbon-zinc battery (ANSI/NEDA 1604D or IEC6F22)

Battery life:

- 30 hours typical (based on a fully charged Ni-MH 250 mAH battery for DC voltage measurement)
- 70 hours typical (based on a new 9 V Alkaline battery for DC voltage measurement)

Charge time:

- Less than 220 minutes in an environment of 10 °C to 30 °C. If the battery has been deep-discharged, a prolonged charging time is required in order for the battery to return to full capacity

POWER CONSUMPTION

- 105 mVA / 420 mVA (with backlight usage) maximum (U1251B)
- 165 mVA / 480 mVA (with backlight usage) maximum (U1252B)

DISPLAY

- Both primary and secondary displays are 5-digit liquid crystal display (LCD) with maximum reading of 50,000 counts
- Automatic polarity indication

OPERATING ENVIRONMENT

- Temperature: Full accuracy from –20 °C to 55 °C.
- Humidity: Full accuracy up to 80% RH (relative humidity) for temperatures up to 35°C, decreasing linearly to 50% RH at 55 °C.
- Altitude:
 - 0 to 2000 meters complying with IEC 61010-1 2nd Edition CAT III, 1000 V/ CAT IV, 600 V.
- Pollution degree II

STORAGE COMPLIANCE

–40 °C to 70 °C with battery removed

SAFETY COMPLIANCE

- EN/IEC 61010-1:2001
- ANSI/UL 61010-1:2004
- CAN/CSA-C22.2 No. 61010-1-04

MEASUREMENT CATEGORY

CAT III 1000 V/CAT IV 600 V Overvoltage Protection

EMC COMPLIANCE

- Certified to IEC61326-1:2005 / EN61326-1:2006
- CISPR 11:2003 / EN 55011:2007 Group 1 Class A
- Canada: ICES-001:2004
- Australia/New Zealand; AS/NZS CISPR11:2004

SHOCK AND VIBRATION

Tested to IEC/EN 60068-2

TEMPERATURE COEFFICIENT

$0.15 \times$ (specified accuracy) / °C (from -20 °C to 18 °C, or 28 °C to 55 °C)

COMMON MODE REJECTION RATIO (CMRR)

> 90 dB at DC, 50/60 Hz \pm 0.1% (1 k Ω unbalanced)

NORMAL MODE REJECTION RATION (NMRR)

> 60 dB at 50/60 Hz \pm 0.1%

DIMENSIONS (W \times H \times D)

94.4 \times 203.5 \times 59 mm

WEIGHT

- 504 \pm 5 grams with battery (U1251B)
 - 527 \pm 5 grams with battery (U1252B)
-

WARRANTY

Please refer to http://www.agilent.com/go/warranty_terms

- Three years for the product
- Three months for the product's standard accessories, unless otherwise specified

Please take note that for the product, the warranty does not cover:

- Damage from contamination
- Normal wear and tear of mechanical components
- Manuals, fuses, and standard disposable batteries

CALIBRATION CYCLE

One year

Measurement Category

The Agilent U1251B and U1252B Handheld Digital Multimeter has a safety rating of CAT III 1000 V/ CAT IV, 600 V.

Measurement category definition

Measurement CAT I are measurements performed on circuits which are not directly connected to the AC mains. For example, measurements on circuits not derived from the AC mains or specially protected (internal) mains-derived circuits.

Measurement CAT II are measurements performed on circuits that are directly connected to a low voltage installation. For example, measurements on household appliances, portable tools and other similar equipment.

Measurement CAT III are measurements performed on building installations. For example, measurements on distribution boards, circuit-breakers, wiring (including cables), bus-bars, junction boxes, switches, socket outlets within the fixed installation, equipment for industrial use and equipment that is permanently connected to the fixed installation such as stationary motors.

Measurement CAT IV are measurements performed at the source of the low-voltage installation. For example, measurements on electricity meters, primary over-current protection devices and ripple control units.

Specification Assumptions

- The DC specifications are defined for measurements which are taken after at least 1 minute of warm-up time.
- The AC and AC+DC specifications are defined for measurements of sine wave and are taken after at least 1 minute of warm-up time.
- The accuracy of the multimeter may be affected when making measurements in an environment where electromagnetic interferences or significant electrostatic charges are present.

Electrical Specifications

DC Specifications

Table 7-1 DC Accuracy \pm (% of reading + Number of Least Significant Digit)

| Function | Range | Resolution | Test Current/ Burden Voltage | Accuracy | |
|------------------------|-----------|------------|---------------------------------|--------------------------|--------------------------|
| | | | | U1251B | U1252B |
| Voltage ^[1] | 50.000 mV | 0.001 mV | - | 0.05 + 50 ^[2] | 0.05 + 50 ^[2] |
| | 500.00 mV | 0.01 mV | - | | |
| | 1000.0 mV | 0.1 mV | - | | |
| | 5.0000 V | 0.0001 V | - | 0.03 + 5 | 0.025 + 5 |
| | 50.000 V | 0.001 V | - | | |
| | 500.00 V | 0.01 V | - | | 0.03 + 5 |
| | 1000.0 V | 0.1 V | - | | |

Notes for DC voltage specifications:

- 1 Input impedance: Refer to [Table 7-19](#).
- 2 The accuracy could be 0.05 % + 10 for U1251B and 0.05 % + 5 for U1252B. Always use the Null function to zero out the thermal effect before measuring the signal.

Table 7-1 DC Accuracy \pm (% of reading + Number of Least Significant Digit) (continued)

| Function | Range | Resolution | Test Current/ Burden Voltage | Accuracy | |
|---------------------------|----------------------------------|-------------------|---------------------------------|-----------|--|
| | | | | U1251B | U1252B |
| Resistance ^[6] | 500.00 Ω ^[3] | 0.01 Ω | 1.04 mA | 0.08 + 10 | 0.05 + 10 |
| | 5.0000 k Ω ^[3] | 0.0001 k Ω | 416 μ A | | |
| | 50.000 k Ω | 0.001 k Ω | 41.2 μ A | 0.08 + 5 | |
| | 500.00 k Ω | 0.01 k Ω | 4.12 μ A | | 0.05 + 5 |
| | 5.0000 M Ω | 0.0001 M Ω | 375 nA | 0.2 + 5 | 0.15 + 5 |
| | 50.000 M Ω ^[4] | 0.001 M Ω | 187 nA | 1 + 10 | 1 + 5 |
| | 500.00 M Ω ^[4] | 0.01 M Ω | 187 nA | - | 3 + 10 < 200M Ω / 8 + 10 > 200M Ω |
| | 500.00 nS ^[5] | 0.01 nS | 187 nA | 1 + 20 | 1 + 10 |

Notes for resistance specifications:

- 3** The accuracy of 500 Ω and 5 k Ω is specified after Null function, which is used to subtract the test lead resistance and the thermal effect.
- 4** For the range of 50 Ω /500 M Ω , the R.H. is specified for < 60 %.
- 5** The accuracy is specified for < 50 nS and after Null function with open test lead.
- 6** Maximum open voltage: < + 4.2 V.

7 Specifications

Table 7-1 DC Accuracy \pm (% of reading + Number of Least Significant Digit) (continued)

| Function | Range | Resolution | Test Current/ Burden Voltage | Accuracy | |
|----------|-------------------------|--------------|---------------------------------|------------------------|-------------------------|
| | | | | U1251B | U1252B |
| Current | 500.00 μ A | 0.01 μ A | 0.06 V | 0.1 + 5 ^[7] | 0.05 + 5 ^[7] |
| | 5000.0 μ A | 0.1 μ A | 0.6 V | 0.1 + 5 ^[7] | 0.05 + 5 ^[7] |
| | 50.000 mA | 0.001 mA | 0.09 V | 0.2 + 5 ^[7] | 0.15 + 5 ^[7] |
| | 440.00 mA | 0.01 mA | 0.9 V | 0.2 + 5 ^[7] | 0.15 + 5 ^[7] |
| | 5.0000 A | 0.0001 A | 0.2 V | 0.3 + 10 | 0.3 + 10 |
| | 10.000 A ^[8] | 0.001 A | 0.4 V | 0.3 + 10 | 0.3 + 5 |

Notes for current specifications:

- 7** Always use the Null function to zero out thermal effect with open test lead before measuring the signal. If the Null function is not used, add 20 counts to the specified accuracy. Thermal effect could occur due to the following:
- Wrong operation — where the resistance, diode, or mV measurement function is used to measure high voltage signals within the range of 50 V to 1000 V.
 - After battery-charging is complete.
 - After measuring a current greater than 440 mA, it is recommended that the meter be left to cool down for twice the length of measurement time used.
- 8** Current can be measured up to 10 A continuously. An additional 0.5% needs to be added to the specified accuracy if the signal measured is in the range of 10 A to 20 A 30 seconds maximum. After measuring current > 10 A, leave the meter to cool down (in switched OFF state) for twice the length of measuring time used before application of low current measurement.

| Function | Range | Resolution | Test Current/ Burden Voltage | Accuracy | |
|------------------------------|-------|------------|---------------------------------|----------|--------|
| | | | | U1251B | U1252B |
| Diode ^{[9][10][11]} | - | 0.1 mV | 1.04 mA | 0.05 + 5 | |

Notes for diode specifications:

- 9** Overload protection: 1000 Vrms for short circuits with < 0.3 A of current.
- 10** Built-in buzzer beeps continuously when the voltage measured is less than 50 mV, and beeps once for forward-based diodes or semiconductor junctions measured between 0.3 V and 0.8 V ($0.3 \text{ V} \leq \text{reading} \leq 0.8 \text{ V}$).
- 11** Open voltage for diode: < + 4.2 V DC.

AC Specifications

AC specifications for U1251B

Table 7-2 U1251B accuracy specifications \pm (% of reading + number of LSD) for true RMS AC voltage

| Function | Range | Resolution | Frequency | | | |
|---------------------------|-----------|------------|----------------|----------------|----------------|-----------------|
| | | | 30 Hz to 45 Hz | 45 Hz to 1 kHz | 1 kHz to 5 kHz | 5 kHz to 30 kHz |
| Voltage ^{[1][2]} | 50.000 mV | 0.001 mV | 1 + 60 | 0.6 + 40 | 1.0 + 40 | 1.6 + 60 |
| | 500.00 mV | 0.01 mV | 1 + 60 | 0.6 + 25 | 1.0 + 40 | 1.6 + 60 |
| | 1000.0 mV | 0.1 mV | 1 + 60 | 0.6 + 25 | 1.0 + 25 | 3.5 + 120 |
| | 5.0000 V | 0.0001 V | 1 + 60 | 0.6 + 25 | 1.0 + 25 | 3.5 + 120 |
| | 50.000 V | 0.001 V | 1 + 60 | 0.6 + 25 | 1.0 + 25 | 3.5 + 120 |
| | 500.00 V | 0.01 V | 1 + 60 | 0.6 + 25 | 1.0 + 25 | - |
| | 1000.0 V | 0.1 V | 1 + 60 | 0.6 + 40 | 1.0 + 40 | - |

Notes for U1251B AC voltage specifications:

- 1 Input impedance: Refer to [Table 7-19](#).
- 2 AC mV/V and AC μ A/mA/A specifications are true RMS AC coupled, valid from 5% to 100% of range. The crest factor may be up to 3 at full scale, up to 5 at half-scale, except for 1000 mV and 1000 V ranges, where the crest factor is 1.5 at full scale and 3 at half scale.

Table 7-3 U1251B accuracy specifications \pm (% of reading + number of LSD) for true RMS AC current

| Function | Range | Resolution | Frequency | | |
|------------------------|-------------------------------|--------------|-----------------------|----------------|-----------------|
| | | | 30 Hz to 45 Hz | 45 Hz to 2 kHz | 2 kHz to 20 kHz |
| Current ^[1] | 500.00 μ A ^[2] | 0.01 μ A | 1.5 + 50 | 0.8 + 20 | 3 + 80 |
| | 5000.0 μ A | 0.1 μ A | 1.5 + 40 | 0.8 + 20 | 3 + 60 |
| | 50.000 mA | 0.001 mA | 1.5 + 40 | 0.8 + 20 | 3 + 60 |
| | 440.00 mA | 0.01 mA | 1.5 + 40 | 0.8 + 20 | 3 + 60 |
| | 5.0000 A | 0.0001 A | 2 + 40 ^[4] | 0.8 + 20 | 3 + 60 |
| | 10.000 A ^[3] | 0.001 A | 2 + 40 ^[4] | 0.8 + 20 | < 3 A/5 kHz |

Notes for U1251B AC current specifications:

- 1 AC mV/V and AC μ A/mA/A specifications are true RMS AC coupled, valid from 5% to 100% of range. The crest factor may be up to 3 at full scale, up to 5 at half-scale, except for 1000 mV and 1000 V ranges, where the crest factor is 1.5 at full scale and 3 at half scale.
- 2 Input current > 35 μ Arms.
- 3 Current can be measured from 2.5 A up to 10 A continuously. Add 0.5% to the specified accuracy if the signal measured is in the range of 10 A to 20 A and for a period of up to 30 seconds. After measuring current > 10 A, leave the meter to cool down for a period that is twice the measuring time used before application of low current measurement.
- 4 Input current < 3 Arms.

7 Specifications

AC specifications for U1252B

Table 7-4 U1252B accuracy specifications \pm (% of reading + number of LSD) for true RMS AC voltage

| Function | Range | Resolution | Frequency | | | | |
|---------------------------|-----------|------------|---------------|---------------|---------------|----------------|---------------------------------|
| | | | 20 Hz – 45 Hz | 45 Hz – 1 kHz | 1 kHz – 5 kHz | 5 kHz – 15 kHz | 15 kHz – 100 kHz ^[1] |
| Voltage ^{[2][3]} | 50.000 mV | 0.001 mV | 1.5 + 60 | 0.4 + 40 | 0.7 + 40 | 0.75 + 40 | 3.5 + 120 |
| | 500.00 mV | 0.01 mV | 1.5 + 60 | 0.4 + 25 | 0.4 + 25 | 0.75 + 40 | 3.5 + 120 |
| | 1000.0 mV | 0.1 mV | 1.5 + 60 | 0.4 + 25 | 0.4 + 25 | 0.75 + 40 | 3.5 + 120 |
| | 5.0000 V | 0.0001 V | 1.5 + 60 | 0.4 + 25 | 0.6 + 25 | 1.5 + 40 | 3.5 + 120 |
| | 50.000 V | 0.001 V | 1.5 + 60 | 0.4 + 25 | 0.4 + 25 | 1.5 + 40 | 3.5 + 120 |
| | 500.00 V | 0.01 V | 1.5 + 60 | 0.4 + 25 | 0.4 + 25 | - | - |
| | 1000.0 V | 0.1 V | 1.5 + 60 | 0.4 + 40 | 0.4 + 40 | - | - |

Notes for U1252B AC voltage specifications:

- 1 The additional error to be added as frequency > 15 kHz and signal input < 10% of range: 3 counts of LSD per kHz.
- 2 Input impedance: Refer to [Table 7-19](#).
- 3 Crest factor \leq 3.0 at full scale, 5.0 at half scale except the 1000 mV and 1000 V ranges where it is 1.5 at full scale, 3.0 at half scale. For non-sinusoidal waveform, add 0.1% of reading \pm 0.3% of range.

Table 7-5 U1252B accuracy specifications \pm (% of reading + number of LSD) for true RMS AC current

| Function | Range | Resolution | Frequency ^[5] | | | |
|------------------------|-------------------------------|--------------|--------------------------|---------------|----------------|------------------------------------|
| | | | 20 Hz – 45 Hz | 45 Hz – 1 kHz | 1 kHz – 20 kHz | 20 kHz – 100 kHz ^{[1][6]} |
| Current ^[5] | 500.00 μ A ^[2] | 0.01 μ A | 1.0 + 20 | 0.7 + 20 | 0.75 + 20 | 5 + 80 |
| | 5000.0 μ A | 0.1 μ A | 1.0 + 20 | 0.7 + 20 | 0.75 + 20 | 5 + 80 |
| | 50.000 mA | 0.001 mA | 1.0 + 20 | 0.7 + 20 | 0.75 + 20 | 5 + 80 |
| | 440.00 mA | 0.01 mA | 1.0 + 20 | 0.7 + 20 | 1.5 + 20 | 5 + 80 |
| | 5.0000 A | 0.0001 A | 1.5 + 20 ^[4] | 0.7 + 20 | 3 + 60 | - |
| | 10.000 A ^[3] | 0.001 A | 1.5 + 20 ^[4] | 0.7 + 20 | < 3 A/5 kHz | - |

Notes for U1252B AC current specifications:

- 1 The additional error to be added as frequency > 15 kHz and signal input < 10% of range: 3 counts of LSD per kHz.
- 2 Input current > 35 μ Arms.
- 3 Current can be measured from 2.5 A up to 10 A continuously. Add 0.5% to the specified accuracy if the signal measured is in the range of 10 A to 20 A and for a period of up to 30 seconds. After measuring current > 10 A, leave the meter to cool down for a period that is twice the measuring time used before application of low current measurement.
- 4 Input current < 3 Arms.
- 5 Crest factor \leq 3.0 at full scale, 5.0 at half scale except the 1000 mV and 1000 V ranges where it is 1.5 at full scale, 3.0 at half scale. For non-sinusoidal waveform, add 0.1% of reading \pm 0.3% of range.
- 6 Verified by design and type tests.

AC+DC Specifications for U1252B

Table 7-6 U1252B true RMS ac+dc voltage specifications

| Function | Range | Resolution | Frequency | | | | |
|------------------------|-----------|------------|------------------|------------------|------------------|-------------------|-----------------------------------|
| | | | 30 Hz – 45 Hz | 45 Hz – 1 kHz | 1 kHz – 5 kHz | 5 kHz – 15 kHz | 15 kHz – 100kHz ^[1] |
| Voltage ^[2] | 50.000 mV | 0.001 mV | 1.5 + 80 | 0.4 + 60 | 0.7 + 60 | 0.8 + 60 | 3.5 + 220 |
| | 500.00 mV | 0.01 mV | 1.5 + 65 | 0.4 + 30 | 0.4 + 30 | 0.8 + 45 | 3.5 + 125 |
| | 1000.0 mV | 0.1 mV | 1.5 + 65 | 0.4 + 30 | 0.4 + 30 | 0.8 + 45 | 3.5 + 125 |
| | 5.0000 V | 0.0001 V | 1.5 + 65 | 0.4 + 30 | 0.6 + 30 | 1.5 + 45 | 3.5 + 125 |
| | 50.000 V | 0.001 V | 1.5 + 65 | 0.4 + 30 | 0.4 + 30 | 1.5 + 45 | 3.5 + 125 |
| | 500.00 V | 0.01 V | 1.5 + 65 | 0.4 + 30 | 0.4 + 30 | - | - |
| | 1000.0 V | 0.1 V | 1.5 + 65 | 0.4 + 45 | 0.4 + 45 | - | - |

Notes for U1252B AC + DC voltage specifications:

- 1 The additional error to be added as frequency > 15 kHz and signal input < 10 %of range: 3 counts of LSD per kHz.
- 2 Input impedance: Refer to [Table 7-19](#).

Table 7-7 U1252B true RMS ac+dc current specifications

| Function | Range | Resolution | Frequency | | |
|----------|-------------------------------|--------------|-------------------------|---------------|----------------|
| | | | 30 Hz – 45 Hz | 45 Hz – 1 kHz | 1 kHz – 20 kHz |
| Current | 500.00 μ A ^[1] | 0.01 μ A | 1.1 + 25 | 0.8 + 25 | 0.8 + 25 |
| | 5000.0 μ A | 0.1 μ A | 1.1 + 25 | 0.8 + 25 | 0.8 + 25 |
| | 50.000 mA | 0.001 mA | 1.2 + 25 | 0.9 + 25 | 0.9 + 25 |
| | 440.00 mA | 0.01 mA | 1.2 + 25 | 0.9 + 25 | 0.9 + 25 |
| | 5.0000 A | 0.0001 A | 1.8 + 30 ^[3] | 0.9 + 30 | 3.3 + 70 |
| | 10.000 A ^[2] | 0.001 A | 1.8 + 30 ^[3] | 0.9 + 25 | < 3 A/5 kHz |

Notes for U1252B AC + DC current specifications:

- 1 Input current > 35 μ Arms.
- 2 Current can be measured from 2.5 A up to 10 A continuously. Add 0.5% to the specified accuracy if the signal measured is in the range of 10 A to 20 A and for a period of up to 30 seconds. After measuring current > 10 A, leave the meter to cool down for a period that is twice the measuring time used before application of low current measurement.
- 3 Input current < 3 Arms.

Capacitance Specifications

Table 7-8 Capacitance specifications

| Range | Resolution | Accuracy ± (% of reading + Offset Error) | Display update rate (approx) |
|-----------|------------|--|------------------------------|
| 10.000 nF | 0.001 nF | 1% + 8 | 4 times/sec. |
| 100.00 nF | 0.01 nF | | |
| 1000.0 nF | 0.1 nF | | |
| 10.000 μF | 0.001 μF | 1% + 5 | 1 time/sec. |
| 100.00 μF | 0.01 μF | | |
| 1000.0 μF | 0.1 μF | | |
| 10.000 mF | 0.001 mF | | |
| 100.00 mF | 0.01 mF | 3% + 10 | 0.01 times/sec. |

Notes for capacitance specifications:

- 1 Use the null operation to zero out residual offset before measuring the signal (by opening the test leads).

Temperature Specifications

Table 7-9 Temperature specifications

| Thermocouple Type | Range | Resolution | Accuracy ± (% of reading + No. of Least Significant Digit) |
|----------------------|-----------------|------------|--|
| K | –200 – 1372 °C/ | 0.1 °C/ | 0.3% + 3 °C/ |
| | –328 – 2502 °F | 0.1 °F | 0.3% + 6 °F |
| J [2] | –210 – 1200 °C/ | 0.1 °C/ | 0.3% + 3 °C/ |
| | –346 – 2192 °F | 0.1 °F | 0.3% + 6 °F |

Table 7-9 Temperature specifications**Notes for temperature specifications:**

- 1 Accuracy of specifications is subject to the following conditions:
 - The accuracy does not include the tolerance of the thermocouple probe. The thermal sensor plugged into the meter should be placed in the operating environment for at least an hour.
 - Use the Null function to reduce the thermal effect. Before using the Null function, set the meter to no ambient compensation (0°C) mode and keep the thermocouple probe as close to the meter as possible, avoiding contact with any surface that has a different temperature from the ambient temperature.
 - When measuring temperature with respect to any temperature calibrator, try to set both the calibrator and the meter with an external reference (without internal ambient compensation). If both the calibrator and the meter are set with internal reference (with internal ambient compensation), deviation may show between the readings of the calibrator and the meter, due to differences in ambient compensation between the calibrator and the meter.
- 2 This thermocouple type is only available for the U1252B.

Frequency Specifications

Table 7-10 Frequency specifications

| Range | Resolution | Accuracy ± (% of reading + Number of Least Significant Digit) | Min. Input Frequency ^[1] |
|------------|------------|---|-------------------------------------|
| 99.999 Hz | 0.001 Hz | | |
| 999.99 Hz | 0.01 Hz | | |
| 9.9999 kHz | 0.0001 kHz | 0.02% + 3 | 1 Hz |
| 99.999 kHz | 0.001 kHz | <600 kHz | |
| 999.99 kHz | 0.01 kHz | | |

Notes for frequency specifications

- 1 The input signal is lower than the product of 20000000V × Hz (product of voltage & frequency); overload protection: 1000 V.
- 2 The multimeter will automatically select the most appropriate range when making frequency measurements.

Duty Cycle and Pulse Width Specifications

Table 7-11 Duty cycle and pulse width specifications

| Function | Mode | Range | Resolution | Accuracy (at full scale) |
|------------|-------------|-----------------|------------|--------------------------|
| Duty cycle | DC Coupling | 0.01% to 99.99% | - | 0.3% per kHz + 0.3% |
| | AC Coupling | 5% to 95% | - | 0.3% per kHz + 0.3% |

7 Specifications

Table 7-11 Duty cycle and pulse width specifications

| Function | Mode | Range | Resolution | Accuracy (at full scale) |
|--|------|---------|------------|--------------------------|
| Notes for duty cycle specifications: | | | | |
| 1 The accuracy for duty cycle and pulse width is based on a 5 V square wave input into the DC 5 V range. | | | | |
| 2 For AC coupling, the duty cycle range can be measured for signal frequency > 20 Hz. | | | | |
| Pulse width | - | 500 ms | 0.01 ms | 0.2% + 3 |
| | - | 2000 ms | 0.1 ms | 0.2% + 3 |

Notes for pulse width specifications:

- 1 The accuracy for duty cycle and pulse width is based on a 5 V square wave input into the DC 5 V range.
- 2 Positive or negative pulse width must be greater than 10 μ s and the range of duty cycle should be considered. The range of pulse width is determined by the frequency of the signal.

Frequency Sensitivity Specifications

For voltage measurements

Table 7-12 Frequency sensitivity and trigger level specifications for voltage measurements

| Input range ^[1] | Minimum sensitivity (RMS sine wave) | | | | Trigger level for DC coupling | | | |
|----------------------------|-------------------------------------|--------------------|-----------------|--------------------|-------------------------------|--------------------|-----------|---------------------|
| | Model Number | | | | | | | |
| | U1251B | | U1252B | | U1251B | | U1252B | |
| | 20 Hz - 100 kHz | >100 kHz - 200 kHz | 20 Hz - 200 kHz | >200 kHz - 500 kHz | < 100 kHz | >100 kHz - 200 kHz | < 100 kHz | > 100 kHz - 500 kHz |
| 50.000 mV | 10 mV | 15 mV | 10 mV | 25 mV | 10 mV | 15 mV | 10 mV | 25 mV |
| 500.00 mV | 25 mV | 35 mV | 70 mV | 150 mV | 60 mV | 70 mV | 70 mV | 150 mV |
| 1000.0 mV | 40 mV | 50 mV | 120 mV | 300 mV | 100 mV | 150 mV | 120 mV | 300 mV |
| 5.0000 V | 0.25 V | 0.5 V | 0.3 V | 1.2 V | 0.5 V/1.25 V (< 100 Hz) | 0.6 V | 0.6 V | 1.5 V |
| 50.000 V | 2.5 V | 5 V | 3 V | 5 V | 5 V | 6 V | 6 V | 15 V |

Table 7-12 Frequency sensitivity and trigger level specifications for voltage measurements

| Input range ^[1] | Minimum sensitivity (RMS sine wave) | | | | Trigger level for DC coupling | | | |
|----------------------------|-------------------------------------|--------------------|-----------------|--------------------|-------------------------------|--------------------|-----------|---------------------|
| | Model Number | | | | | | | |
| | U1251B | | U1252B | | U1251B | | U1252B | |
| | 20 Hz - 100 kHz | >100 kHz - 200 kHz | 20 Hz - 200 kHz | >200 kHz - 500 kHz | < 100 kHz | >100 kHz - 200 kHz | < 100 kHz | > 100 kHz - 500 kHz |
| 500.00 V | 25 V | - | 30 V < 100 kHz | - | 50 V | - | 60 V | - |
| 1000.0 V | 50 V | - | 50 V < 100 kHz | - | 300 V | - | 120 V | - |

Notes for frequency sensitivity and trigger level specifications for voltage measurements;

- 1 Maximum input for specified accuracy = 10 x range or 1000 V
- 2 The input signal is lower than the product of 20,000,000 V-Hz

For current measurements

Table 7-13 Frequency sensitivity specifications for current measurements

| Input Range | Minimum Sensitivity (R.M.S. sine wave) |
|----------------|--|
| | 20 Hz – 20 kHz |
| 500.00 μ A | 100 μ A |
| 5000.0 μ A | 250 μ A |
| 50.000 mA | 10 mA |
| 440.00 mA | 25 mA |
| 5.0000 A | 1 A |
| 10.000 A | 2.5 A |

Peak Hold Specifications

Table 7-14 Peak hold specifications for dc voltage and current measurements

| Signal Width | Accuracy For DC mV/voltage/current |
|--------------------------|------------------------------------|
| Single event > 1 ms | 2% + 400 for all ranges |
| Repetitive > 250 μ s | 2% + 1000 for all ranges |

Frequency Counter Specifications for U1252B

Table 7-15 Frequency counter (divide by 1) specifications

| Range | Resolution | Accuracy \pm (% of reading + No. of Least Significant Digit) | Sensitivity | Min. Input Frequency |
|------------|------------|---|---------------|----------------------|
| 99.999 Hz | 0.001 Hz | 0.02% + 3 ^[1] | 100 mV R.M.S. | 0.5 Hz |
| 999.99 Hz | 0.01 Hz | | | |
| 9.9999 kHz | 0.0001 kHz | | 200 mV R.M.S. | |
| 99.999 kHz | 0.001 kHz | 0.002% + 5 | | |
| 999.99 kHz | 0.01 kHz | < 985 kHz | | |
| 9.9999 MHz | 0.0001 MHz | | | |

Table 7-16 Frequency counter (divide by 100 ^[4]) specifications

| Range | Resolution | Accuracy ± (% of reading + No. of Least Significant Digit) | Sensitivity | Min. Input Frequency |
|------------|------------|---|---------------|----------------------|
| 9.9999 MHz | 0.0001 MHz | 0.002 % + 5, | 400 mV R.M.S. | 1 MHz |
| 99.99 MHz | 0.001 MHz | < 20 MHz | 600 mV R.M.S. | |

Notes for frequency counter specifications:

- 1 All frequency counters are susceptible to error when measuring low-voltage, low-frequency signals. Shielding inputs from picking up external noise is critical for minimizing measurement errors. For non-square wave signals, an additional 5 counts need to be added.
- 2 The maximum measurement level is < 30 Vpp.
- 3 The minimum measurement frequency of low frequency is set by power-on option to speed up the measurement rate.
- 4 Shown on the secondary display.

Square Wave Output for U1252B

Table 7-17 Square wave output specifications

| Output ^[1] | Range | Accuracy |
|----------------------------------|--|---------------------------------------|
| Frequency | 0.5, 1, 2, 5, 10, 15, 20, 25, 30, 40, 50, 60, 75, 80, 100, 120, 150, 200, 240, 300, 400, 480, 600, 800, 1200, 1600, 2400, 4800 Hz | 0.005% x output frequency + 2 counts |
| Duty Cycle ^{[2][4][5]} | 0.39% – 99.60% | ± 0.398% of full scale ^[3] |
| Pulse Width ^{[2][4][6]} | 1/Frequency | 0.2 ms + (range/256) |
| Amplitude | Fixed 0 to + 2.8 V | ± 0.2 V |

7 Specifications

Table 7-17 Square wave output specifications

Notes for square wave output specifications:

- 1 Output impedance: 3.5 k Ω maximum.
 - 2 The positive or negative pulse width must be greater than 50 μ s for adjusting the duty cycle or the pulse width under different frequencies. Otherwise the accuracy and the range will be different from the definition.
 - 3 For signal frequencies greater than 1 kHz, add 0.1% per kHz to the accuracy.
 - 4 The accuracy for duty cycle and pulse width is based on a 5 V square wave input without dividing signal.
 - 5 Duty cycle can be set for 256 steps and each step is 0.390625% per kHz.
 - 6 The pulse width can be set for 256 steps and each step is $1/(256 \times \text{Frequency})$.
-

Operating Specifications

Display update rate (approximate)

Table 7-18 Display update rate (approximate)

| Function | Times/second |
|------------------------------|-------------------|
| AC V | 7 |
| AC V + dB | 7 |
| DC V (V or mV) | 7 |
| AC V (V or mV) | 7 |
| AC+DC V (V or mV) | 2 |
| Ω / nS | 14 |
| Diode | 14 |
| Capacitance | 4 (< 100 μ F) |
| DC A (μ A, mA, or A) | 7 |
| AC A (μ A, mA, or A) | 7 |
| AC+DC A (μ A, mA, or A) | 2 |
| Temperature | 6 |
| Frequency | 1 (> 10 Hz) |
| Duty cycle | 0.5 (> 10 Hz) |
| Pulse width | 0.5 (> 10 Hz) |

NOTE

The U1251B and U1252B handheld digital multimeter does **not** contain a realtime clock. Only **ONE** sample per second can be logged.

Input impedance

Table 7-19 Input Impedance

| Function | Range | Input Impedance |
|--------------------------------|-----------|------------------------------------|
| DC Voltage ^{[1][3]} | 50.000 mV | 10.00 M Ω |
| | 500.00 mV | 10.00 M Ω |
| | 1000.0 mV | 10.00 M Ω |
| | 5.0000 V | 11.10 M Ω |
| | 50.000 V | 10.10 M Ω |
| | 500.00 V | 10.01 M Ω |
| | 1000.0 V | 10.001 M Ω |
| AC Voltage ^[2] | 50.000 mV | 10.00 M Ω |
| | 500.00 mV | 10.00 M Ω |
| | 1000.0 mV | 10.00 M Ω |
| | 5.0000 V | 10.00 M Ω |
| | 50.000 V | 10.00 M Ω |
| | 500.00 V | 10.00 M Ω |
| | 1000.0 V | 10.00 M Ω |
| AC + DC Voltage ^[2] | 50.000 mV | 10.00 M Ω |
| | 500.00 mV | 10.00 M Ω |
| | 1000.0 mV | 10.00 M Ω |
| | 5.0000 V | 11.10 M Ω // 10 M Ω |
| | 50.000 V | 10.10 M Ω // 10 M Ω |
| | 500.00 V | 10.01 M Ω // 10 M Ω |
| | 1000.0 V | 10.001 M Ω // 10 M Ω |

Notes for input impedance:

- For 5 V to 1000 V range, the specified input impedance in parallel with 10 M Ω at dual display.
- The specified input impedance (nominal) in parallel with <100 pF.
- For 5 V to 1000 V range, the specified input impedance is in parallel with 10 M Ω when the input voltage is >+3 V or <-2 V [only applicable for the Agilent U1252B Handheld Digital Multimeter]

www.agilent.com

Contact us

To obtain service, warranty or technical support assistance, contact us at the following phone numbers:

United States:

(tel) 800 829 4444 (fax) 800 829 4433

Canada:

(tel) 877 894 4414 (fax) 800 746 4866

China:

(tel) 800 810 0189 (fax) 800 820 2816

Europe:

(tel) 31 20 547 2111

Japan:

(tel) (81) 426 56 7832 (fax) (81) 426 56
7840

Korea:

(tel) (080) 769 0800 (fax) (080) 769 0900

Latin America:

(tel) (305) 269 7500

Taiwan:

(tel) 0800 047 866 (fax) 0800 286 331

Other Asia Pacific Countries:

(tel) (65) 6375 8100 (fax) (65) 6755 0042

Or visit Agilent worldwide Web at:
www.agilent.com/find/assist

Product specifications and descriptions in this document are subject to change without notice. Always refer to the English version on the Agilent Web site for the latest revision.

© Agilent Technologies, Inc. 2009–2013

Printed in Malaysia
Tenth Edition, August 12, 2013

U1251-90036



Agilent Technologies